

The VMARS Archive

VMARS is a not-for-profit organisation specialising in all types of vintage communications electronics. We maintain an archive of documentation to help our members understand, research, repair and enjoy their vintage radio equipment. Access by non-members is extended as a gesture of goodwill, but not as a right.

Rare documents are frequently provided free of charge by VMARS members, and all scanning and document processing is carried out on a voluntary basis. Accordingly, we do not expect others to profit from the hard work of volunteers, who give their time freely without charge.

This is a gentle reminder that the document attached to this notice is provided to you for your personal use only. This edition remains copyright of VMARS, and while you may sell or give your copy to someone else, this right does not extend to making further copies of this information, either to give or sell to others. This includes a prohibition on placing it on websites, or printing it for sale at rallies, boot fairs or similar public events. If our goodwill is abused, then withdrawal of public access to our archive will be the result.

Please refer anyone else wanting a copy back to VMARS – either to our website at <http://www.vmars.org.uk/> or by email to the Archivist at archivist@vmarsmanuals.co.uk. If you want to know more about our copyright, please see the FAQ below.

FAQ on copyright of VMARS documents

- Q** How can you copyright a document that is already in the public domain?
- A.** *Plainly the original copyright of the content has expired, or we have obtained permission to copy them. What we copyright is our own edition of the document.*
- Q.** Surely your “own edition” is identical to the original document, so cannot be copyrighted?
- A.** *Our editions are **not** identical to the original document. You will find that full advantage has been taken of electronic publishing facilities, so pages are cleaned up where possible (rendering them better than originals in some cases!), and large diagrams are prepared for both on-screen viewing and for easy printing at A4 format.*
- Q.** Why do you not just give your manuals away, as so many do via the internet these days?
- A.** *We do make all our manuals available free of charge (in soft copy) to VMARS members. These members have already covered the costs of running the archive via their subscriptions. The only time members are charged for copies is when they request them on paper, in which case charges are restricted to the cost of paper, ink and postage.*

The VMARS archive is not a “shoe-string” operation. Money is spent on computing facilities to make copies available, and on shipping original documents securely (usually costing several pounds per shipment) to carry out the scanning. As members have already contributed to these costs, it is only reasonable that non-members should do likewise – and thus a very moderate charge is levied for copies provided to non-members. With typical commercial photocopying charges starting at 5 pence per A4 side, it will be evident that paying 4 pence for our equivalent on paper is excellent value (amounts current at Spring 2004). We also think “you get what you pay for” – we invite you to make the comparison and draw your own conclusions!

Despite the above, we will be making copies of essential technical information (circuit diagram, parts list, layout) freely available to all via our website from late 2004 onwards. This will be done to try and encourage and enable the maintenance of our remaining stock of vintage electronic equipment.

Guidance on using this electronic document

Acrobat Reader version

You need to view this document with Acrobat Reader **version 5.0** or later. It is possible that the document might open with an earlier version of the Acrobat Reader (thus allowing you to get this far!), but is also likely that some pages will not be shown correctly. You can upgrade your Acrobat Reader by direct download from the internet at <http://www.adobe.com/products/acrobat/readermain.html> or going to <http://www.adobe.com/> and navigating from there.

Printing the document on A4 paper

You should note first that virtually all original documents are in double-sided format, i.e. printed on both sides of the paper. Accordingly, our copies are similarly double-sided., and the best results are obtained if the document is printed double-sided. You can print out on one side only, but you will find that you get a number of blank sheets (which can just be removed and reused), and where margins vary in width between left-hand and right-hand pages, there is a danger of the text disappearing into the binding of your printed copy.

This document is of fairly simple format in that it can be made to print out using an A4 format printer (this is the common paper size available in UK and Europe, which measures 29.7cm by 21.0cm). By “simple” I mean that there are no large diagrams on fold out sheets, which will require multiple A4 pages to print out at full size.

Original document sizes do vary a lot – from the small manuals, which approximate to A5 size (21.0 x 14.8 cm) up to the now obsolete foolscap size (21.6 x 33.0 cm). US documents tend to use their “letter” size paper (21.6 x 27.9 cm). All these sizes can be printed on A4 paper by simply getting Acrobat to shrink or enlarge the pages as necessary. This is done as follows:

1. Select “File – Print” or click on the printer icon. This will bring up the print dialog box.
2. Select the correct printer if necessary.
3. Select the pages you want to print – even if you want to print all of the document, you will probably not want to print this notice and help page, so start the printing at page 3.
4. In the “Page Handling” area, next to “Page Scaling”, select “Fit to paper”. The press “OK”

Printing the document on an US Letter format printer

Since A4 and US Letter sizes are similar, it is expected that this document should print satisfactorily on the latter format paper. This has not been tested however, and is not guaranteed. Follow the steps as for A4 printing, and make doubly sure that “Fit to paper” is selected (step 4).

Any other problems?

Please get in touch with me at archivist@vmarsmanuals.co.uk.

Richard Hankins, VMARS Archivist, Summer 2004

CONDITIONS OF RELEASE

(Applicable to copies supplied with War Office approval to Commonwealth and Foreign Governments)

1. This document contains classified UK information.
2. This information is disclosed only for official use by the recipient Government, and (if so agreed by HM Government) such of its contractors, under seal of secrecy, as may be engaged on a defence project. Disclosure or release to any other Government, national of another country, any unauthorized person, the Press, or in any other way would be a breach of the conditions under which the document is issued.
3. This information will be safeguarded under rules designed to give the same standard of security as those maintained by HM Government in the UK.

STATION, RADIO, A510

TECHNICAL HANDBOOK - INSPECTION STANDARDS

INTRODUCTION

1. This regulation details the inspection standards to be observed during field inspection and after field or base repair.
2. Departure from these standards will not be permitted unless authorized by War Office or DEME of the overseas theatre concerned.
3. These standards cover the following aspects of inspection:-

- (a) **Field inspection schedule.** This details the tests and test methods to be carried out when inspecting equipment in the hands of troops. The limits and tolerances quoted also will be observed as minimum field repair standards.
- (b) **Field inspection record.** This is for the use of an examiner when inspecting equipment in the hands of troops, or after field repair.
- (c) **Base inspection schedule.** To avoid repetition this schedule has been omitted. Where necessary direct reference to the equipment EMERs is included in the base inspection record.

- (d) **Base inspection record.** This details the standards to be observed during base repair and subsequent inspection of the equipment. The standards will apply to all base workshops, and will be used as a guide by other workshops engaged in repair, and during the inspection of depot stocks.

References

4. TELS A 619 - EMER specification for inspection standards, telecommunications equipment.
- TELS A 760 - Repainting of electronic equipment
- TELS A 779 - General standard for the overhaul of electronic equipment
- TELS F 560-9 - Station, radio, A510

FIELD INSPECTION SCHEDULE

Introduction

5. This part of the regulation is to be used when inspecting equipment in the hands of the troops. The field inspection record gives the condemnation limits beyond which the equipment will not carry out its task efficiently.
6. Using these condemnation limits as the standard, examiners should classify the equipment in accordance with the latest ACI. When the equipment is serviceable but barely satisfies the minimum standards in the field inspection record the symbol 'O' must be used to indicate that the equipment should be kept under observation with facilities available. If the facilities are not available to the unit the equipment may have to be downgraded. In borderline cases, particularly where quantitative measurements are not given, the final assessment must be based on the examiner's experience and judgment using the standard as a guide.

This being a sealed equipment, inspection is restricted to the examination of external components and to those tests which can be applied to input and output connections.

General specification

7. The equipment and all accessories will be inspected for general cleanliness and will be free from moisture and fungoid growth.
8. Paintwork will be free from cracking, chipping or flaking. Where patch painting has been carried out uniformity of colour need not be considered.
9. Panel components and controls will be securely mounted and functional.
10. Accessories and station spares will be complete and serviceable.

11. Outstanding modifications will be recorded.

Z4/6625-99-949-0510 Wattmeter, absorption AF, No 1

Electrical tests

Z4/10S/831 Oscilloscope, type 13A

12. The electrical tests are detailed in the field inspection record. Further information regarding method and test conditions is given in Tels F 564.

Z4/6625-99-949-0470 Voltmeter, valve, No 3, equipment

Test equipment

* 60dB attenuator

13. The following test equipment and accessories will be required:-

* 75Ω dummy load

* 2kΩ dummy load

ZD/02674 Signal generator, No 12
ZC/1411 Frequency meter, SCR 211

* For further details see Tels F 564

FIELD INSPECTION RECORD

14. In the following particulars paragraph numbers refer to Tels F 564.

Item	Test	Specification limits			Result
		Min	Max	Unit	
GENERAL					
1	Cleanliness	-	-	-	
2	Paintwork	-	-	-	
3	Components and controls	-	-	-	
4	Accessories and station spares	-	-	-	
5	Modifications	-	-	-	
RECEIVER					
6	R.F.sensitivity (para 52) Connect S.G.12 (X1, 75Ω) to aerial socket and earth; a.f. wattmeter (100Ω) to contacts 4 and 5 of SKT2. Tune S.G.12 to 2Mc/s and receiver for maximum output A.F. output for 5μV input	200	-	μW	
7	Signal-to-noise ratio (para 53) Conditions as for item 6. Adjust input to produce 200μW output switch off modulation Residual noise	-	20	μW	
8	Dial calibration (para 51) Conditions as for item 6. Check calibration of frequency dial at each Mc/s point Low band High band	-	50	kc/s	
		-	100	kc/s	
TRANSMITTER					
9	R.F. output - low impedance (para 59 and 60) Check that the crystals are inserted in their respective positions. Connect a 75Ω dummy load and V.V.3 between aerial socket and earth. Set A-B NET to B, CRYSTAL to 1, MATCHING to 0 and control switch to CW. With key depressed tune for maximum output				

Item	Test	Specification limits			Result
		Min	Max	Unit	
10	Output voltage	6.14	-	V	
	Switch to VOICE				
	Output voltage reference c.w. output	43	56	%	
	Repeat at crystal positions 2, 3 and 4				
11	R.F. output - high impedance (para 61)				
	Replace 75Ω load with 2kΩ load. Set A-B-NET to A, CRYSTAL to 1 and control switch to CW. Tune for maximum output on AERIAL TUNE METER				
	Output voltage	32	-	V	
	Switch to VOICE				
12	Output voltage reference c.w. output	45	65	%	
	Modulation sensitivity (para 62)				
	Conditions as in item 10 but with C.R.O. in place of V.V.3. Connect B.F.O. No 8 via attenuator to contacts 1 and 4 of SKT2. On VOICE, adjust B.F.O. No 8 to give approximately 50-80% modulation pattern. Adjust frequency of B.F.O. No 8 to produce maximum depth of modulation				
	Frequency	900	1500	c/s	
13	At this frequency, adjust B.F.O. No 8 output to give 100% modulation				
	B.F.O. output	30	-	V	
	FUNCTIONAL				
	Netting				
14	On receive and net, tune receiver to sender crystal frequency				
	Zero-beat to be heard in phones				
13	Clear audio tone either side of zero				
	Dial lock				
14	Net as in item 12. Operate dial lock four times				
	Netting signal must not be lost				
14	Pilot lamps				
	Illuminate as detailed below				
		Switch positions		Lamp	
		Control	A-B-NET		
		CW	All	Sender	
		R	A & B	Receiver	
		R	Net	Both	
		VOICE	All	Sender	

BASE INSPECTION RECORD

15. The specification figures quoted are based on measurements made using the test equipment detailed in Tels F 564 Tables 1 and 2.

16. In the following particulars paragraph numbers refer to Tels F 564.

Item	Test	Specification limits			Result
		Min	Max	Unit	
	GENERAL				
1	The general condition will be in accordance with Tels A 779				
	RECEIVER				
2	Audio sensitivity (para 46) Connect a.f. wattmeter (100Ω) to contacts 4 and 5 of SKT2; B.F.O. No 8, V.V.3. and 40dB attenuator to pin 3 of V5 via 0.5μF capacitor Input at 1kc/s for output of 200μW	-	0.2	V	
3	Audio response (para 47) Conditions as for item 2 Output at 0.3kc/s Output at 3kc/s Reference input at 1kc/s to produce 200μW	50 63	- -	μW μW	
4	I.F. sensitivity (para 48) Connect S.G.12 (X1, 75Ω) via 0.1μF capacitor to pin 6 of V2; a.f. wattmeter (100Ω) to contacts 4 and 5 of SKT2 Modulated input for 200μW output (Note actual input) Frequency for maximum output	- 454	50 456	μW kc/s	
5	I.F. selectivity (para 49) Conditions as for item 4. Increase input by 6dB. Tune S.G.12 to each side of resonance where output falls to 200μW Bandwidth Repeat with input increased by 60dB Bandwidth	4.95 22.5	6.05	kc/s kc/s	
6	Heterodyne oscillator (para 50) Conditions as for item 4. Tune S.G.12 for maximum a.f. output, adjust input to give 200μW. Switch off modulation, plug phones into SKT2 and key into SKT3 Beat note	-	1	kc/s	
7	Dial calibration (para 51) For this and following tests, insert receiver into case. Couple frequency meter to aerial socket and check calibration of frequency dial at each Mc/s point Low band High band	- -	50 100	kc/s kc/s	
8	R.F. sensitivity (para 52) Connect S.G.12 (X1, 75Ω) to aerial socket and earth; a.f. wattmeter (100Ω) to contacts 4 and 5 of SKT2. Tune S.G.12 to 2Mc/s and receiver for maximum output A.F. output for 5μV input Repeat at 4.5Mc/s (low band) and at 5Mc/s and 10Mc/s (high band)	200	-	μW	

Item	Test	Specification limits			Result
		Min	Max	Unit	
9	Signal-to-noise ratio(para 53) Conditions as for item 8. Adjust input to produce 200 μ W output Switch off modulation Residual noise Repeat at 4.5Mc/s (low band) and at 5Mc/s and 10Mc/s (high band)	-	20	μ W	
10	Second channel rejection (para 54) Conditions as for item 8. At frequencies below, tune S.G.12 and receiver and adjust input to give 200 μ W output. Retune S.G.12 to image frequency (+0.91Mc/s), increase input to give 200 μ W output. Check the image ratio at:- 2Mc/s 4.5Mc/s 5Mc/s 10Mc/s	60 46 46 36	- - - -	dB dB dB dB	
11	I.F. rejection (para 55) Conditions as for item 8. Tune S.G.12 to 2Mc/s, output 5 μ V. Tune receiver for maximum output, adjust gain control to give 200 μ W output. Retune S.G.12 to 455kc/s Input required to produce 200 μ W output	50	-	mV	
12	A.G.C. operation (para 56) Conditions as for item 8. Tune S.G.12 to 10Mc/s, output 5 μ V. Tune receiver for maximum output. Increase S.G.12 output to 50mV, adjust receiver gain for 200 μ W output. Reduce S.G.12 output to 10 μ V. A.F. output	20	-	μ W	
13	Low voltage operation (para 57) At reduced voltages (h.t. 66V, l.t. 1.1V). Replace a.f. wattmeter by phones. Adjust S.G.12 to 5Mc/s, 10 μ V, modulation depth 30%. Signal in phones and clear netting on both bands				
	TRANSMITTER				
14	R.F. output - low impedance (para 59 and 60) Insert 2, 4.5, 7.5 and 10Mc/s crystals Connect either 75 Ω dummy load with V.V.3 or wattmeter, h.f., No 2, (52 Ω , 1W) between aerial and earth. Set A-B-NET to B, CRYSTAL to 1, MATCHING to 0 and control SW to CW. With key depressed, tune for maximum output Output voltage Output power Switch to VOICE Output voltage reference c.w. output Output power reference c.w. output Repeat at crystal positions 2, 3 and 4	6.14 0.5 43 18	- - 56 32	V W % %	
15	R.F. output - high impedance (para 61) Connect 2k Ω dummy load with V.V.3 between aerial and earth. Set A-B-NET to A, CRYSTAL to 1 and control SW to CW. Tune for maximum output on the AERIAL TUNE METER Output voltage	32	-	V	

Item	Test	Specification limits			Result
		Min	Max	Unit	
16	Switch to VOICE				
	Output voltage reference c.w. output Repeat at crystal positions 2 and 3	45	65	%	
	Modulation sensitivity (para 62) Conditions as in item 15 but with C.R.O. in place of V.V.3. Connect B.F.O. No 8 via 60dB attenuator to contacts 1 and 4 of SKT2. On VOICE, adjust B.F.O. No 8 to give approximately 50-80% modulation pattern. Adjust frequency of B.F.O. No 8 to produce maximum depth of modulation				
17	Frequency	900	1500	c/s	
	At this frequency, adjust B.F.O. No 8, output to give 100% modulation				
	B.F.O. output	30	-	V	
18	Low voltage operation (para 63) Conditions as for item 13 but with low voltage supply h.t. 66V, l.t. 1.1V)				
	Output voltage (c.w.)	4.75	-	V	
	Output power (c.w.)	0.5	-	W	
18	Seal testing (para 64 and 65) Initial pressure 10 lb/sq.in.				
	Time constant	36	-	hr	

EME8c/835

END