

The VMARS Archive

VMARS is a not-for-profit organisation specialising in all types of vintage communications electronics. We maintain an archive of documentation to help our members understand, research, repair and enjoy their vintage radio equipment. Access by non-members is extended as a gesture of goodwill, but not as a right.

Rare documents are frequently provided free of charge by VMARS members, and all scanning and document processing is carried out on a voluntary basis. Accordingly, we do not expect others to profit from the hard work of volunteers, who give their time freely without charge.

This is a gentle reminder that the document attached to this notice is provided to you for your personal use only. This edition remains copyright of VMARS, and while you may sell or give your copy to someone else, this right does not extend to making further copies of this information, either to give or sell to others. This includes a prohibition on placing it on websites, or printing it for sale at rallies, boot fairs or similar public events. If our goodwill is abused, then withdrawal of public access to our archive will be the result.

Please refer anyone else wanting a copy back to VMARS – either to our website at <http://www.vmars.org.uk/> or by email to the Archivist at archivist@vmarsmanuals.co.uk. If you want to know more about our copyright, please see the FAQ below.

FAQ on copyright of VMARS documents

- Q** How can you copyright a document that is already in the public domain?
- A.** *Plainly the original copyright of the content has expired, or we have obtained permission to copy them. What we copyright is our own edition of the document.*
- Q.** Surely your “own edition” is identical to the original document, so cannot be copyrighted?
- A.** *Our editions are **not** identical to the original document. You will find that full advantage has been taken of electronic publishing facilities, so pages are cleaned up where possible (rendering them better than originals in some cases!), and large diagrams are prepared for both on-screen viewing and for easy printing at A4 format.*
- Q.** Why do you not just give your manuals away, as so many do via the internet these days?
- A.** *We do make all our manuals available free of charge (in soft copy) to VMARS members. These members have already covered the costs of running the archive via their subscriptions. The only time members are charged for copies is when they request them on paper, in which case charges are restricted to the cost of paper, ink and postage.*

The VMARS archive is not a “shoe-string” operation. Money is spent on computing facilities to make copies available, and on shipping original documents securely (usually costing several pounds per shipment) to carry out the scanning. As members have already contributed to these costs, it is only reasonable that non-members should do likewise – and thus a very moderate charge is levied for copies provided to non-members. With typical commercial photocopying charges starting at 5 pence per A4 side, it will be evident that paying 4 pence for our equivalent on paper is excellent value (amounts current at Spring 2004). We also think “you get what you pay for” – we invite you to make the comparison and draw your own conclusions!

Despite the above, we will be making copies of essential technical information (circuit diagram, parts list, layout) freely available to all via our website from late 2004 onwards. This will be done to try and encourage and enable the maintenance of our remaining stock of vintage electronic equipment.

Guidance on using this electronic document

Acrobat Reader version

You need to view this document with Acrobat Reader **version 5.0** or later. It is possible that the document might open with an earlier version of the Acrobat Reader (thus allowing you to get this far!), but is also likely that some pages will not be shown correctly. You can upgrade your Acrobat Reader by direct download from the internet at <http://www.adobe.com/products/acrobat/readermain.html> or going to <http://www.adobe.com/> and navigating from there.

Don't miss the index!

This document has had “bookmarks” added – which provide you with an “on-screen index”. These allow you to quickly move to particular parts of the document, a numbered section or maybe the circuit diagrams for instance, merely by clicking on the page title. Click on the “Bookmarks” tab on the left hand side of the Acrobat Viewer window to access this feature – move the cursor over these titles and notice it change shape as you do so. Click on any of these titles to move to that page.

Large diagrams

The large diagrams are given in two formats – in A4 size sheets to allow easy printing, and complete as originally published to allow easy on-screen viewing. These versions are in different sections of the document, which can be found within the bookmarks.

Printing the document on an A4 format printer

The document has been optimised for printing on A4 size paper (this is the common size available in UK and Europe, which measures 29.7cm by 21.0cm). Please follow these steps (these are based on Acrobat Reader version 6.0 – other versions may differ in detail):

1. Work out the page numbers you want to print. If you want to print the whole document, then within “Bookmarks” (see above), first click on “**Front**”, and note the page number given at the bottom of the Acrobat window – this will give you the page number of the first page to be printed. Similarly click on “**End of A4 printable copy**”, to determine the last page to be printed.
2. Select “File – Print” or click on the printer icon. This will bring up the print dialog box.
3. Select the correct printer if necessary.
4. In the area marked “Print Range” click on the radio button marked “Pages from..”, then enter the first and last page numbers worked out in step 1 into the “from” and “to” boxes.
5. In the “Page Handling” area, next to “Page Scaling”, select “Fit to paper”. Then press “OK”

Note that the document is set up for double-sided printing – if you print it out single-sided then you will find a number of blank pages present, which may be removed and reused.

Printing the document on an US Letter format printer

Since A4 and US Letter sizes are similar, it is expected that this document should print satisfactorily on the latter format paper. This has not been tested however, and is not guaranteed. Follow the steps as for A4 printing, and make doubly sure that “Fit to paper” is selected (step 5).

Any other problems?

Please get in touch with me at archivist@vmarsmanuals.co.uk.

Richard Hankins, VMARS Archivist, Summer 2004

RESTRICTED

AIR PUBLICATION

2528M

VOLUME 1

ARI. 18041

**SINGLE-CHANNEL VHF
EQUIPMENT
TR2002 AND TR2002A**

**GENERAL AND TECHNICAL
INFORMATION**

Prepared by direction of
the Ministry of Aviation

Henry Handman

Promulgated by Command
of the Air Council

L. J. Dean.

AIR MINISTRY

THE PATENT 'LOXON' LOOSE-LEAF
BINDER

Patent Nos. 700547 and 802577

HOW TO USE THIS BINDER

AS A COVER FOR PRINTED MATTER

When reading from the Book, the sheets should be kept firmly bound up, thus avoiding any chance of wear and tear at the holes. If, however, for any reason, leaves are required to be viewed from edge to edge, then the laces should be disengaged from the spring clips and fully slackened off. The Binder and the sheets can then be spread open to lie flat.

AS A NOTEBOOK

When writing, so that the leaves shall lie quite flat, disengage the laces from the spring clips and slacken them fully.

TO INSERT OR REMOVE LEAVES

(Without the leaves being freed from the control of the laces at any time)

Unhitch the laces from the spiral springs, unthread the laces from the flange and join together the two ends of each lace thus forming two separate loops. Draw the tags through to the required place, disconnect, insert or remove sheets.

REF. F 3447

AMENDMENT RECORD SHEET

To record the incorporation of an Amendment List in this publication, sign against the appropriate A.L. No. and insert the date of incorporation.

A.L. No.	Amended by	Date
1 to 17	Incorporated in this reprint	Sept. 1962
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		
29		
30		
31		
32		
33		
34		
35		
36		
37		
38		
39		
40		
41		
42		
43		
44		
45		
46		
47		
48		

A.L. No.	Amended by	Date
49		
50		
51		
52		
53		
54		
55		
56		
57		
58		
59		
60		
61		
62		
63		
64		
65		
66		
67		
68		
69		
70		
71		
72		
73		
74		
75		
76		
77		
78		
79		
80		
81		

(67252)

(Continued overleaf)

RESTRICTED

A.L. No.	Amended by	Date
82		
83		
84		
85		
86		
87		
88		
89		
90		
91		
92		
93		
94		
95		
96		
97		
98		
99		
100		
101		
102		
103		
104		
105		
106		
107		
108		
109		
110		
111		
112		
113		
114		
115		
116		
117		
118		

A.L. No.	Amended by	Date
119		
120		
121		
122		
123		
124		
125		
126		
127		
128		
129		
130		
131		
132		
133		
134		
135		
136		
137		
138		
139		
140		
141		
142		
143		
144		
145		
146		
147		
148		
149		
150		
151		
152		
153		
154		
155		

RESTRICTED

NOTE TO READERS

The subject matter of this publication may be affected by Air Ministry Orders, or by "General Orders and Modifications" leaflets in this A.P., or even in some others. If possible, Amendment Lists are issued to correct this publication accordingly, but it is not always practicable to do so. When an Order or leaflet contradicts any portion of this publication, the Order or leaflet is to be taken as the overriding authority.

The inclusion of references to items of equipment does not constitute authority for demanding the items.

Each leaf bears the date of issue and, when applicable, the number of the Amendment List with which it was issued. New or amended technical information on new leaves which are inserted when this publication is amended will be indicated by a vertical line in the margin. This line merely denotes a change and is not a mark of emphasis. When a Section or Chapter is issued in a completely revised form, the line will not appear.

★ ★ ★

ASSOCIATED PUBLICATIONS

	A.P.
<i>10-Channel VHF and airborne relay equipment</i>	2538HA
<i>Multimeter Type CT38</i>	2879AG
<i>Instruction book for frequency meter set SCR.211D</i> ...	33A1-5-19-1 (TM11-300)
<i>R.A.F. signal manual, electrical equipment (airborne)</i> ...	1186D
<i>Signal generator Type 31</i>	2879P
<i>Signal generator Type 56</i>	2879D
<i>Signal generator Type 62</i>	2536BN
<i>Test kit Type 7</i>	2538J
<i>Common test gear for radio equipment</i>	2536C

RESTRICTED

LIST OF PARTS AND PRELIMINARY MATTER

PRELIMINARIES

Amendment record sheet

Note to readers

Layout of A.P.2528M (to be issued later)

Leading particulars (~~to be issued later~~) A/C 2

PARTS

1 General description and technical information

2 Servicing (~~to be issued later~~) A/C 7

3 Fault diagnosis (~~to be issued later~~) A/C 8

RESTRICTED

LEADING PARTICULARS OF ARI.18041

Transmitter-receiver Type TR2002 and TR2002A

General

<i>Stores ref.</i>	10D/17997 TR. 2002 10D/22941 TR.2002A
<i>Purpose of equipment</i>	Single channel v.h.f. communications equipment for airborne use
<i>Type of transmission</i>	Voice
<i>Frequency</i>	121.5Mc/s
<i>Frequency control</i>	Crystal-controlled ; separate crystals for transmitter and receiver
<i>Crystal mult. factor</i>	Transmitter, 12 ; receiver, 8
<i>Power supply</i>	24V d.c., normally derived from two 12V accumulators, (5J/3307) housed in battery box Type 15
<i>Power consumption</i>	Not more than 62W
<i>Range</i>	Approx. 80 nautical miles at 5000 ft

TRANSMITTER

<i>Type</i>	Transmitter unit Type 98 or Type 98A
<i>Stores ref.</i>	Type 98 10R/176 Type 98A 10R/149
<i>R.F. output</i>	Minimum of 1W into 45-ohm line
<i>Modulation and harmonic content</i>	Amplitude modulation up to 100%. The harmonic content is not greater than 12% at 80% modulation with 1000 c/s tone
<i>Audio frequency response characteristic</i>	With a constant input which gives 80% modulation depth at 1 kc/s, the output for a frequency excursion of 500 c/s to 3 kc/s is within ± 4 dB relative to the output at 1 kc/s. Below 500 c/s the attenuation exceeds 5 dB per octave relative to the level at 500 c/s

RECEIVER

<i>Type</i>	Receiver unit Type 127
<i>Stores ref.</i>	10P/13202
<i>Intermediate frequency</i>	9.72 Mc/s $\pm 0.01\%$
<i>I.F. bandwidth</i>	At 6 dB down, not less than ± 35 kc/s At 40 dB down, not greater than ± 130 kc/s
<i>Sensitivity</i>	R.F. input required for 30 μ A diode current is not greater than 10 μ V
<i>Signal/noise ratio</i>	For an r.f. input of 10 μ V modulated at 1 kc/s to a depth of 30%, the signal to noise ratio is not less than 20dB
<i>Second channel suppression</i>	Not less than 50 dB
<i>A.G.C.</i>	For an increase in r.f. input from 10 μ V to 100mV the increase in demodulator diode current is not more than +6dB

Note . . .

All r.f. inputs are quoted as open circuit voltage from a 50-ohm source.

RESTRICTED

PRINCIPAL ITEMS OF A TYPICAL INSTALLATION ARI. 18041

	<i>Overall Dimensions</i>			
	<i>Height (in.)</i>	<i>Width (in.)</i>	<i>Depth (in.)</i>	<i>Wt. (lb.)</i>
<i>Transmitter receiver Type TR2002 or TR2002A</i>	7½	4¾	12	9
<i>Mounting Type 1028 (10AJ/209)</i>				
<i>(Mounting increases the overall height of transmitter-receiver by 1in.</i>				
<i>or</i>				
<i>Mounting Type 1031 (10AJ/212)</i>				
<i>Battery box Type 15 (10AP/189)</i>	5½	4¾	11½	12 (with batteries)
<i>Mounting Type 1029 (10AJ/210)</i>				
<i>(Mounting increases the overall height of battery box by ¼ in.)</i>				
<i>Attenuator units Type 7157 (10L/292)</i>				
<i>Switch, magnetic relay, Type S4 (5C/3945)</i>				
<i>Switch, tumbler, Rotax (5C/4182)</i>				
<i>Switch, tumbler</i>				
<i>Aerial, aircraft, Type 226</i>				
<i>10B/16566</i>				
<i>Connector set</i>				

Note

Installations employing carbon microphones will require an adaptor.

VALVES

<i>Circuit reference</i>	<i>Function</i>	<i>CV No.</i>
<i>Transmitter</i>		
1V1 and 1V2	<i>Speech amplifiers</i>	2135
1V3 and 1V4	<i>Modulators</i>	416
1V5	<i>Oscillator and frequency trebler</i>	416
1V6	<i>1st frequency doubler</i>	416
1V7	<i>2nd frequency doubler</i>	416
1V8	<i>Power amplifier</i>	416
<i>Receiver</i>		
2V1	<i>R. F. amplifier</i>	850
2V2	<i>Frequency changer</i>	850
2V3, 2V4, 2V5	<i>1st, 2nd and 3rd i.f. amplifiers</i>	131
2V6	<i>Detector and a.g.c. delay</i>	140
2V7	<i>A.F. amplifier</i>	138
2V8	<i>Oscillator and frequency quadrupler</i>	850
2V9	<i>Frequency doubler</i>	850

Crystals

<i>Transmitter</i>	=10.125 Mc/s	} <i>Type 10X/ZDH/ (tolerance 0.005% -20 to +70°C)</i>
<i>Receiver</i>	=13.9725 Mc/s	

Fuses 250mA cartridge Type 153 (10H/18680)

RESTRICTED

PART 1

**GENERAL DESCRIPTION AND
TECHNICAL INFORMATION**

LIST OF CHAPTERS

Note.—A list of contents appears at the beginning of each chapter

- 1 General description and operating instructions**
- 2 Detailed circuit description (A.L.3)**
- 3 Installations (A.L.11)**
- 4 Transmitter Receiver Type TR.2002A (A.L.17)**

RESTRICTED



Chapter 1

GENERAL DESCRIPTION AND OPERATING INSTRUCTIONS

LIST OF CONTENTS

	Para.		Para.
<i>Introduction</i>	1	<i>Structural description</i>	
<i>Circuit summary</i>		<i>Transmitter-receiver</i>	8
<i>Transmitter unit</i>	4	<i>Battery box Type 15</i>	15
<i>Receiver unit</i>	6	<i>Typical installation</i>	16
		<i>Operating instructions</i>	19

LIST OF ILLUSTRATIONS

	Fig.
<i>Transmitter-receiver Type TR2002, general view</i>	1
<i>Transmitter-receiver Type TR2002, block diagram</i>	2
<i>Transmitter-receiver, case removed</i>	3

Introduction

1. ARI. 18041 is intended for emergency and standby use in aircraft. A typical installation (*para.* 16) includes a transmitter-receiver Type TR2002 or TR2002A, a battery box Type 15, a relay unit, a V.H.F. switch, a power supply switch, an aerial Type 226 and suitable connectors. The transmitter-receiver (*fig.* 1) is a single-channel, light-weight airborne equipment for voice communication. It operates on a carrier frequency of 121.5 Mc/s, the frequency being controlled by two crystals, one for the transmitter and one for the receiver. In addition, Type TR2002A has the facility for intercommunication which can be switched in or out as required; details of TR2002A are given in Chap. 4. The transmitter range under normal conditions is approximately 80 miles at an altitude of 5000 ft.

2. The transmitter-receiver is normally quite independent of the aircraft power system, the operating power being obtained from two 12-volt accumulators (Ref. 5J/3307) connected in series to give 24V. These accumulators are housed in a special battery box (Type 15). The output from the accumulators supplies the valve heaters and also operates a motor-generator (located on the transmitter chassis) which in turn provides a 170V h.t. supply necessary for the operation of the transmitter and the receiver. In some installations provision is made for the equipment to be operated from the normal aircraft supply.

3. Fig. 1 shows the transmitter-receiver complete with case. It is of the "miniaturized" type, the transmitter unit and receiver unit, together with the motor generator and its associated smoothing circuits, being contained in a case measuring only 7¼ in. × 4¼ in. × 12 in.; the total weight of this assembly is 9 lb.



Fig. 1. Transmitter-Receiver Type TR.2002, General View

RESTRICTED

Circuit summary

Transmitter unit

4. Reference to fig. 2 shows that the transmitter employs a crystal-controlled oscillator valve (1V5), which also serves as a frequency-trebler. This stage is followed by two frequency doubler stages (1V6 and 1V7), giving a final output frequency of twelve times the crystal fundamental frequency; this output is applied to a power amplifier (1V8).

5. The a.f. output from the microphone is applied through a microphone transformer to the grids of the push-pull speech amplifier valves (1V1, 1V2).

1V2). The amplified a.f. signal passes thence to the push-pull modulator stage (1V3, 1V4). The output from this stage is used to modulate the r.f. output of the power amplifier (1V8), and the resulting modulated r.f. output is applied to the aerial, through the contacts of the aerial change-over relay. Sidetone is taken from the secondary of the modulation transformer and applied to the a.f. stage of the receiver. The motor-generator used to provide the h.t. supply is included in the transmitter chassis, together with the associated filter circuits. This is not indicated on the diagram, but is covered in the detailed circuit description given in Chapter 2.




Fig. 2. Transmitter-Receiver Type TR.2002, Block Diagram

Receiver unit

6. The receiver circuit (fig. 2) employs a crystal-controlled oscillator valve (2V8) which also serves as a frequency quadrupler. The output from this stage is passed through a frequency doubler stage (2V9). The final frequency, which is eight times the crystal fundamental frequency, is applied to the frequency-changer stage (2V2).

7. The output from the single r.f. stage (2V1) is applied to the frequency-changer stage (2V2), where it is combined with the oscillator output to provide an i.f. frequency of 9.72 Mc/s. This stage is followed by three i.f. amplifiers (2V3, 2V4, 2V5) and a diode detector which uses one half of a double diode valve (2V6a). The resulting a.f. signal is amplified by valve 2V7, and the amplified signal applied to the telephones. A portion of the rectified i.f. voltage developed across the detector diode load resistors is used for a.g.c. purposes, and is

applied to the grids of the r.f., frequency-changer, and first and second i.f. valves. A.G.C. delay is provided, and the second section of the double-diode valve (2V6b) is used to control this. A complete description of this circuitry is given in Chapter 2.

Structural description

Transmitter-receiver

8. The transmitter-receiver consists of a transmitter unit and a receiver unit mounted one above the other on a front panel and protected by a light alloy case; the receiver is mounted at the top. Fig. 1 shows the external appearance of the assembled equipment. When installed in the aircraft the transmitter-receiver is normally mounted on an anti-vibration mounting to which it is secured by two locating spigots at the rear, and two knurled nuts at the front end.

Case

9. The case, as shown, is provided with louvres for the circulation of cooling air. The air circulation is assisted by a cooling fan on the motor-generator mounted on the transmitter chassis. This fan draws air through a gauze-covered aperture in the rear of the case and impels it forward into the chassis, whence it escapes via the louvres.

10. The case is secured to the transmitter-receiver by two coin-slotted captive screws which engage with tapped bushes in the rear flanges of the transmitter and receiver chassis.

Front panel

11. This is the principal structural member of the equipment, since it serves as mounting rack for the transmitter and receiver. All external connections to the transmitter and receiver units are made through three plugs mounted on the front panel (*fig. 1*). One of these plugs (PL6) is of the coaxial type and takes the aerial connection. The remaining two plugs are of the Plessey type. The lower one, PL2, takes the connection from the 24-volt battery, while the upper one, PL1, provides the remainder of the connections, including those for telephones, microphone and control circuits. Two cartridge-type fuse holders, F1 and F2, mounted below the aerial plug, contain the fuses for the transmitter and the receiver HT supplies, respectively. Two further fuse holders mounted on the panel below F1 and F2 contain spare fuses; they are in no way connected to the circuitry of the equipment. A carrying handle is provided at the bottom of the panel.

12. The transmitter and receiver units are assembled on the back of the panel as shown in *fig. 3*. It is seldom necessary to remove the transmitter unit from the panel, consequently it is secured by normal screws with locknuts or lockwashers. It may, however, be necessary to remove the receiver unit for access to components on its lower side, or to components on top of the transmitter chassis. Consequently, it is secured to the panel only by four captive screws, and may be electrically disconnected from the remainder of the equipment by releasing and withdrawing the coaxial socket SK3 and the eight-pole socket SK2. The rear mounting plate which assists in supporting the receiver unit has a projecting pin at each corner; the two upper pins engage with holes in the rear flange of the receiver chassis, and the lower two engage similar holes in the rear flange of the transmitter chassis. The mounting plate is secured by the single recessed screw visible in the illustration.

Transmitter and receiver chassis

13. The transmitter and receiver chassis are of the normal light-alloy, box-form type. Brackets spot-welded to each side of the chassis enable them to be secured to the front panel. Four spring contacts, one mounted on each bracket, provide electrical connection between the chassis and case. The transmitter chassis carries the motor generator and the associated filter circuitry in addition to the transmitter components. The connection between




Fig. 3. Transmitter-receiver, case removed

the aerial change-over relay and the transmitter is by a coaxial socket SK1. The remainder of the connections between the front panel and the transmitter are by permanent wiring, as the transmitter and panel are not normally separated. The connections from the various transmitter test points are taken to two 6-pole plugs at the rear of the chassis (*fig. 3*).

14. As noted in para. 12, the receiver chassis is removable from the front panel, all connections to it being made through sockets SK2 and SK3 of the panel, which engage with corresponding plugs PL4 and PL1 on the chassis. The receiver chassis is stepped-down at the left-hand side to provide more room for the IF transformers, and has a curved guard plate attached to its forward end to prevent damage to the wiring at the rear of the front panel. Four test points are provided on the receiver, the connections to them being made via a six-pole plug mounted near the co-axial plug, and a 2-pole plug mounted towards the rear of the receiver.

Battery box Type 15

15. Battery box Type 15 contains the standby accumulators. It consists of a metal case with ventilating louvres in the sides and a detachable cover secured by a large knurled nut. A socket and terminal block are mounted on the front of the box, the connections to the installation being made through the socket; the terminal block facilitates testing of the accumulator voltage, or serves for the connection of additional items of equipment. A simple metal strip carrier is provided for each accumulator to facilitate its insertion or removal from the box. To safeguard the accumulators, non-absorbent sponge rubber packings are provided in the case, on the lid, and on the carriers.

The complete battery box, when installed in the aircraft, is secured in a mounting Type 1029 by two locating spigots at the rear and two spring latches at the front. The accumulators used are capable of maintaining their full charge capacity for a period of four weeks, provided that no discharge has taken place.

TYPICAL INSTALLATION

16. Complete information regarding the installations ARI.18041 is not available at the time of going to press, but the following paragraphs may be taken as summarizing a typical installation. Diagrams and descriptions of specific installations will be issued in Chapter 3 as the information becomes available.

17. A typical installation ARI.18041 will include a transmitter-receiver Type TR.2002 (with anti-vibration mounting Type 1028), a battery box Type 15 (with mounting Type 1029, and containing two 12-volt accumulators), a relay unit Type S4, a single-pole two-way switch marked POWER SUPPLY NORMAL—STANDBY, and a two-pole two-way switch marked VHF NORMAL—STANDBY; a separate aerial Type 226 is also provided. In some installations, where carbon microphones are used, a special attenuator unit is included.

18. The POWER SUPPLY switch enables the standby equipment to be operated either from the NORMAL aircraft power supply or from the STANDBY batteries. When the two-pole VHF switch is set to STANDBY one of its poles connects the power supply (selected by the POWER SUPPLY switch) to the standby transmitter-receiver; the other pole of this switch controls the relay unit Type S4. The relay unit connects the telephones, microphone and

press-to-transmit switch either to the NORMAL VHF equipment or to the STANDBY equipment, depending on the setting of the VHF switch.

OPERATING INSTRUCTIONS

19. Differences may exist between installations, e.g., alternative power supplies may not be provided in some instances; the following instructions apply to a typical installation.

20. As noted in para. 16, the controls introduced by ARI.18041 are two in number, a POWER SUPPLY switch, and a VHF switch. These switches should be operated as follows:—

- (1) If the normal VHF equipment has failed but the aircraft power supply system is in order, leave the POWER SUPPLY switch at NORMAL and set the VHF switch to STANDBY. The standby equipment is now in action and connected to the telephones, microphone and PRESS-TO-TRANSMIT switch of the normal installation; these may now be used in the usual manner.
- (2) If the normal power supply fails, set both the POWER SUPPLY and the VHF switch to STANDBY and proceed as before.

Note . . .

The maximum time for which the standby batteries will operate TR.2002 (no other load being applied) is 1½ hours at normal temperatures, falling to ¾ hour at 0 deg. C. The duration at intermediate and lower temperatures will vary accordingly. For this reason the standby batteries must not be used for testing the equipment on the ground. All such testing should be done on the aircraft power supply.

Chapter 2

DETAILED CIRCUIT DESCRIPTION

LIST OF CONTENTS

	Para.		Para.
Introduction... ..	1	Receiver unit Type 127	12
Transmitter unit Type 98	3	Control and power circuits	25

LIST OF ILLUSTRATIONS

	Fig.		Fig.
Transmitter unit Type 98, block diagram... ..	1	Simplified control, interconnection and power supply diagram	6
Bottom view of transmitter chassis	2	Bottom view of receiver chassis	7
Top view of transmitter chassis	3	Top view of receiver chassis	8
Receiver unit Type 127, block diagram	4	Transmitter unit Type 98, circuit... ..	9
Simplified detector and AGC circuit	5	Receiver unit Type 127, circuit	10

Introduction

1. The complete transmitter-receiver Type TR. 2002 comprises a case, a transmitter unit Type 98 and a receiver unit Type 127. The structural aspects of the equipment are dealt with in Chap. 1. The input power supply for the equipment is 24V DC, and is derived from accumulators. This 24V supply provides the heater current for the valves and is also used to drive a rotary transformer, the output from which provides a 170V HT supply both for the transmitter and the receiver. As the equipment operates on a single pre-tuned channel, no channel-selecting circuitry is required.

2. The rotary transformer and the associated smoothing circuit components are mounted on the transmitter chassis. These components, together with the components (plugs, send/receive relay, etc.) mounted on the front panel, form part of transmitter unit Type 98, and are indicated on the transmitter circuit diagram, fig. 9; for convenience

of description, however, they are here considered under the separate heading "Control and power circuits" (*para. 25 to 28*).

Transmitter unit Type 98

3. From the block diagram (*fig. 1*) it will be seen that the actual transmitter portion of the unit comprises a crystal oscillator and frequency-trebler stage (1V5) followed by two frequency-doubler stages (1V6 and 1V7) and a power amplifier (1V8). The output from the microphone is applied via a push-pull speech amplifier stage (1V1, 1V2) and a push-pull modulator stage (1V3, 1V4) to the power amplifier stage (1V8). The resulting modulated RF output is applied to the aerial through the contacts of a send/receive relay. Sidetone is taken from the secondary of the modulation transformer and applied to the AF stage of the receiver. The complete transmitter circuit is shown in fig. 9; fig. 2 and 3 will assist in locating any specific component in the transmitter.




Fig. 1. Transmitter unit Type 98, block diagram

Crystal oscillator

4. The beam tetrode 1V5 (*fig. 9*) serves both in the crystal oscillator and in the frequency-trebler circuits. When considering the oscillator circuit the cathode, control grid and second grid may be regarded as a triode, the second grid serving as "anode" to this portion of the circuit, while the true anode forms part of the frequency-trebling circuit.

5. A crystal 1XL1 (fundamental frequency 10·125 Mc/s) is connected between the control grid of 1V5 and earth, and positive feedback is obtained by connecting two capacitors 1C8 and 1C9 in series with each other and in shunt across the crystal in the Colpitts manner, the junction of the capacitors being connected to the cathode of 1V5. The cathode is maintained at an RF potential by an inductor 1L5, which also serves to complete the cathode DC path to earth. A meter plug 1PL5/3, connected across 1R14 (part of the grid-leak chain 1R13, 1R14), enables an indication of the grid current, and consequently of the amplitude of oscillation, to be obtained.

Frequency trebler

6. Valve 1V5 serves also as a frequency trebler. Energy is transferred within the valve from the oscillatory circuit to the anode circuit by electron coupling and, since the anode circuit is tuned by inductor 1L4 and capacitor 1C10 to the third harmonic of the crystal frequency, the output frequency of the anode circuit will be three times the crystal fundamental frequency, or 30·375 Mc/s. Resistor 1R16 and capacitor 1C11 provide decoupling for the frequency trebler, and 1R15 and 1C7 for the oscillator portion of 1V5. Automatic bias is applied to the control grid by the voltage drop across resistors 1R13 and 1R14 due to grid current.

First and second frequency doublers

7. The output from the oscillator-trebler stage is applied to the grid of the first frequency-doubler valve, beam pentode 1V6, through capacitor 1C12. The anode circuit comprises an inductor 1L6 which is tuned by the preset capacitor 1C15 to the second harmonic of the output frequency of the trebler stage, consequently the output frequency of this stage will be 60·750 Mc/s. The anode and the second grid of 1V6 are decoupled by 1R20, 1C19 and 1R17, 1C14, respectively. Automatic grid bias is obtained from the voltage drop across 1R18 and 1R19, and a meter plug 1PL4/3 connected across 1R19 enables an indication to be obtained of the excitation applied to this stage. The second frequency-doubler stage is similar to the first, with the exception that the anode circuit of this stage is tuned to the second multiple of the output frequency of the first doubler stage, consequently the final frequency will be 121·5 Mc/s. The meter plug for this stage is 1PL4/2.

Power amplifier

8. The output from the second frequency-doubler stage is applied through capacitor 1C22 to the grid of the power amplifier valve 1V8, and as the anode circuit of this valve includes an inductor 1L9 tuned


by a preset capacitor 1C24 to the same frequency as the anode circuit of 1V7, it follows that the frequency of the amplified RF output will also be 121·5 Mc/s. The HF supply for the second grid and the anode of the power amplifier is taken through resistor 1R10 and the secondary winding of the modulation transformer 1TR2. From the above it will be seen that the AF voltages developed across the secondary winding of the transformer are in series with the HT voltage, and consequently will appear in the anode and screen circuits of 1V8, and so modulate the RF output of that stage. Capacitor 1C25 in conjunction with the normal filter consisting of 1R25 and 1C23 serves to decouple the second grid of 1V8 for RF, and a filter comprising inductor 1L8 and capacitor 1C26 prevents the RF output of the power amplifier from feeding back into the HT line and so affecting the other stages. The modulated RF output is applied to the aerial through capacitor 1C27, coaxial plug 1PL3 (on the transmitter chassis), socket 1SK1 (wired to the front panel), the send/receive relay 1SR/2, and the aerial plug 1PL6 (on the front panel). To enable indications of the grid and of the anode and screen current of the power amplifier stage to be obtained, a plug 1PL4/1 is connected across resistor 1R27 of the grid leak chain, and a plug 1PL5/2 is connected (in series with resistor 1R12) across resistor 1R10 in the anode circuit.

Speech amplifier

9. The microphone output is applied through pins C and D of plug 1PL1 as a balanced input to the centre-tapped primary of the microphone transformer 1TR1. The secondary of this transformer is also centre-tapped, the tapping being earthed and the resulting anti-phase output is taken from the extremities of the winding are applied to the grids of the speech amplifier valves 1V1 and 1V2 through resistors 1R1 and 1R2 respectively. These pentode valves work in push-pull circuit, and automatic bias is applied to both valves by a cathode resistor 1R6, which is bypassed by capacitor 1C28.

Modulator

10. The amplified signal from 1V1 and 1V2 passes through capacitors 1C2 and 1C3 to the grids of the push-pull modulator valves 1V3, 1V4. These valves, which are of the beam tetrode type, are supplied with a fixed cathode bias of +12V taken from the centre point of the series-connected valve heater chain. The outputs from 1V3 and 1V4 are applied to the extremities of the centre-tapped primary winding of transformer 1TR2, the HT voltage being applied to the tapping of this winding through a resistor 1R9 which also serves as meter shunt when checking the modulator anode and screen current at plug 1PL5/1. A voltage-dropping series resistor 1R12 is common both to the modulator and to the power amplifier check points. The AF voltages which appear in the secondary of the modulator transformer are applied to the anode and screen circuits of the power amplifier valve 1V8 and modulate the RF output of that valve as described in para. 8. A portion of the AF output from the modulator transformer is used as sidetone, being applied through resistor 1R11, capacitor 1C5 and pole 7 of 1SK2 to the AF amplifier stage of the receiver.



ALL REF NUMBERS HAVE PREFIX I

Fig.2 Bottom view of transmitter chassis Fig.2

RESTRICTED




Fig.3 Top view of transmitter chassis Fig.3

RESTRICTED

Valve heater circuit

11. As the LT supply is 24V (nominal) and the valve heaters are designed for 6.3V, it is necessary to wire the heaters in a series-parallel arrangement. By reason of the differing heater currents required for the various valves, it is easier to consider the transmitter and receiver valves together. The combined heater circuit which results when the loose socket 1SK2 (permanently wired to the transmitter and panel circuits) and plug 2PL4 (on the receiver) are engaged is indicated in fig. 6. The heater arrangement may now be considered as consisting of four series-connected chains. Valves 1V5, 1V6, 1V7 and 1V8 of the transmitter all require the same current (0.3A) and are connected in series across the 24V supply; 2V8, 2V9, 2V2 and 2V1 of the receiver all require 0.175A, and are similarly connected. The heaters of the transmitter valves 1V4 and 1V3 require 0.3A, and are connected in series with the parallel heaters of 1V1 and 1V2 (0.15A each) and thence through pole 3 of plug 1SK2 and socket 2PL4 to earth via the heater of 2V6, which also requires 0.3A. This leaves a chain of three heaters, 2V3, 2V4 and 2V5 (0.2A) in series with 2V7. As the latter heater requires 0.3A, a resistor 2R42 is connected in parallel with the three series-connected heaters of 2V3, 2V4 and 2V5. The interconnections between the heater chains of the 6, 12 and 18 volt levels assist in securing correct voltage distribution across the heater chains. The positive cathode bias for the modulator valves is taken from the centre point (12V approx.) of the transmitter heater chain. Capacitors 2C56, 2C57, 2C58 and 2C59 in the receiver are provided at the 6, 18 and 24V levels to filter out any RF interference arising in the rotary transformer.

Receiver unit Type 127

12. As indicated in the block diagram, fig. 4, the receiver employs one RF amplifying stage, a frequency changer, three IF amplifiers, a diode detector, which also provides the AGC voltage,

and one AF amplifier stage. The oscillator stage serves also as a frequency quadrupler, and is followed by a frequency doubler stage. The AGC voltage derived from the detector stage is applied to the RF, the frequency changer, and the first and second IF stages. AGC delay is provided, and an AGC delay valve is introduced to prevent the possibility of the positive delay voltage appearing in the AGC line. The complete receiver circuit is shown in fig. 10 and reference to the annotated illustrations fig. 7 and 8 will assist in locating any specific component in the receiver.

RF input

13. The signals received by the aerial are transferred through the send/receive relay to the receiver aerial plug 2PL1, and so to a tapping on an inductor 2L2 which is in the grid circuit of the RF amplifier valve 2V1 (fig. 10). This inductor is tuned to the frequency of the incoming signal by a preset capacitor 2C4, and the grid is coupled to this tuned circuit by a capacitor 2C3; the latter capacitor also serves to prevent the AGC voltage which is parallel-fed to the grid of 2V1 from shorting to earth through inductor 2L2. An inductor 2L1 in series with a capacitor 2C1 is connected between the tapping on 2L2 and earth. This combination is tuned to 102.06 Mc/s, and forms an image acceptor circuit to prevent the image frequency from appearing in the receiver.

RF amplifier

14. The gain of the RF pentode valve is controlled by the AGC voltage which is parallel-fed to its grid through resistor 2R3. To ensure that the valve will always have a certain minimum amount of bias no matter how low the AGC voltage, a small amount of automatic bias is applied by means of resistor 2R7, which is bypassed for RF by 2C7 and 2C10. The screen grid voltage is obtained from a potential divider connected across the HT supply and consisting of two resistors, 2R1 and 2R2; capacitor 2C2




Fig. 4. Receiver unit Type 127, block diagram

RESTRICTED

rectified in 2V6a, and the resulting AF voltages, plus a DC component due to rectification of the carrier, appear across the diode load resistors 2R24, 2R25, 2R26 and 2R27. The AF output from this stage is taken from the slider of a potentiometer 2VR1 which, in series with a capacitor 2C39, is connected across 2R25 and 2R26 of the diode load. This potentiometer is of the preset type and controls the audio-frequency output to the AF amplifier stage. Capacitor 2C39 serves as a DC stopper. Bypass capacitors 2C37 and 2C38 are connected at the junction of 2R24 with the IF transformer and with 2R25, respectively to form an IF filter. A meter plug 2PL3 connected across resistor 2R26 of the diode load enables an indication of the diode current to be obtained.

Automatic gain control

20. As noted in para. 19, when a signal is being received a DC voltage proportional to the received signal appears across the diode load resistors 2R24, 2R25, 2R26 and 2R27. By reason of the direction of current flow through the detector diode 2V6a, the anode end of the resistor chain will be negative with regard to the cathode, or earthy end. A proportion of this negative voltage, taken from the junction of 2R24 and 2R25, (the point marked C on fig. 5) is used for automatic gain control (AGC), and is applied through the AGC line to the grids of the RF, frequency-changer, and first and second IF stages. This AGC voltage is parallel-fed to the RF and frequency-changer stages, and series-fed to the first and second IF stages. As the AGC voltage is proportional to the incoming signal, it follows that a strong signal will produce a larger, and a weak signal a smaller, negative bias on the grids of the controlled stages, so providing automatic correction for changes in signal strength by varying the gain of these stages. Suitable bypass capacitors are provided at each of these stages, and capacitor 2C32 in conjunction with resistors 2R3, 2R12, and 2R16 prevent the AF component from affecting the controlled stages.

AGC delay

21. As noted in the preceding paragraph, the negative voltage appearing at point C is proportional to the strength of the received signal. If this voltage were applied direct to the controlled stages it would reduce the sensitivity of the receiver even on weak signals and it is therefore desirable to "delay" its application until the strength of the received signal exceeds a certain pre-determined level. In this receiver a delay of approximately 4.75V has been introduced, i.e., no AGC bias is applied to the controlled valves until the signal received is of such strength as to develop a DC voltage across 2R25, 2R26, 2R27 in excess of this value.

22. Fig. 5 shows the circuitry involved. Resistors 2R30 (270K) and 2R31 (120K) are connected in series between +170V and earth, consequently the junction A of these resistors will be approximately 52.3V positive with regard to earth. A potential divider consisting of 2R29 (10M) and 2R28 (1M)

is connected between point A and point C (the point on the detector diode load from which the AGC bias is taken), and the AGC line is connected to point B, the junction of 2R29 and 2R28. Ignore 2V6b for the moment, and assume that the equipment is switched on and that no signal is being received; there will now be no current flow through the detector diode load, and consequently no negative voltage at point C. Under these conditions, point A is connected to earth through resistors 2R29, 2R28, 2R25, 2R26 and 2R27, and consequently the voltage at point B will be approximately 4.75V. This is the delay voltage, and as it is in opposition to the negative AGC voltage which appears at point C when a signal is being received, it follows that no negative AGC voltage can reach the controlled valves until a signal is received of strength sufficient to produce a voltage drop across 2R25, 2R26, 2R27 greater than 4.75V.

23. If the circuit were left as described above it would be possible, when no, or weak, signals were being received, for the positive delay voltage to appear in the AGC line. To prevent this from occurring, the second half of the double diode valve, 2V6b, is inserted between point B and earth, the cathode being connected to earth. So long as the normal negative bias is present in the AGC line, valve 2V6b will be in the non-conducting state, and consequently will not affect the circuit. If, however, the signal strength should fall to a level at which the positive delay voltage tends to appear at point B, the diode will conduct, effectively maintaining the AGC line at earth potential.

AF amplifier

24. The output from the detector to the grid of the AF valve 2V7 may be adjusted by the preset potentiometer 2RV1 (fig. 10). As in the other stages, automatic cathode bias is provided, the resistor in this instance being 2R33, and the cathode bypass capacitor being 2C43. The HT supply for the RF, IF and oscillator stages is taken through pin 8 of plug 2PL4, and is controlled by the send/receive relay. As the AF stage is used to amplify not only the received signals but also the transmitter side tone, a separate unswitched HT supply is necessary, and this is obtained through pin 4 of 2PL4. 2R34 is the voltage-dropping resistor for the screen supply, and is bypassed for AF by the capacitor 2C41. Capacitor 2C44 bypasses any RF which may appear in the anode circuit. The output from this stage is coupled to the load through transformer 2TR5, the output impedance being 150 ohms.

Note . . .

The heater circuits of the receiver are described in para. 11.

Control and power circuits

25. The control circuits, power circuits and the interconnections between the transmitter and the receiver are indicated in the simplified diagram, fig. 6. This diagram also indicates the external associated items in the simplest terms. In actual




Fig. 6. Simplified control, interconnection and power supply diagram

installations the circuitry external to the transmitter-receiver will be more complicated than it is here indicated, but the effects, in-so-far as the transmitter-receiver is concerned, will be the same. For details of the complete installations refer to Chap. 3.

26. Referring to fig. 6, it is seen that the 24V DC supply is applied to poles A and B of plug 1PL2, the aerial is connected through the coaxial plug 1PL6 to contacts 1SR2 of the send/receive relay, and the microphone, telephones, power on-off switch and the press-to-transmit switch are connected through plug 1PL1.

27. When the power switch is ON, current from the 24V battery flows through the 250 ohm winding of relay 1PO/1, causing contacts 1PO1 to close. This permits the 24V supply to reach the heater circuits of the transmitter and, through

socket 1SK2 and plug 2PL4, of the receiver. The 24V supply also passes to the input brushes of the rotary transformer through inductors 1L1 and 1L2, with the result that the 170V HT supply becomes available at the output brushes, and passes through inductor 1L3 to contacts 1SR1 of the send/receive relay. The HT supply is smoothed by the 2 microfarad capacitor 1C1, inductors 1L1, 1L2 and 1L3 are provided to suppress RF interference from the brushes of the rotary transformer, and 0.01 microfarad capacitors are included in the heater circuit to complete the suppression. It will be noted, from the diagram, that the total load current passes through a low-resistance limit-hold winding of relay 1PO/1.

28. When the press-to-transmit switch is in the normal (receive) position, the send/receive relay is in the unenergized condition (as shown in the diagram), with the result that the aerial is con-

nected through relay contacts 1SR2, coaxial socket 1SK3 and plug 2PL1 to the receiver circuits, and the HT supply passes through relay contacts 1SR1 and pole 8 of socket 1SK2 and plug 2PL4 to all stages of the receiver with the exception of the AF stage. The AF stage of the receiver serves as side-tone amplifier when the transmitter is in use, and for this reason the HT supply to this stage is fed directly to the receiver through pole

4 of 1SK2 and 2PL4, and is not controlled by the send/receive relay. If the press-to-transmit switch is now set to the transmit position, the send/receive relay will be energized, contacts 1SR2 change the aerial over from the receiver input to the transmitter output circuit, and contacts 1SR1 transfer the HT supply from the receiver (with the exception of the AF stage) to the transmitter circuits.

RESTRICTED




Fig.7 Bottom view of receiver chassis Fig.7

RESTRICTED




Fig. 8 Top view of receiver chassis Fig. 8

RESTRICTED





Fig. 9

Transmitter unit Type 98 - circuit

RESTRICTED



Transmitter unit Type 98 - circuit

Fig.9

RESTRICTED

(AL.12 May 55)





Fig.10


Receiver unit Type

R E S T R I



* ON THE FIRST 75 EQUIPMENTS 2C38 IS .002 μ
2C39 IS .001 μ

HEATERS



mit Type 127 - circuit
TRICATED

Fig. 10

TABLE I
Principal items of a typical installation ARI.18041

Ref. No. in fig. 1	Description	Stores Ref.
(1)	Transmitter-receiver Type TR.2002	10D/17997
	<i>with</i>	
	Mounting Type 1028	10AJ/209
	<i>or</i>	
	Mounting Type 1031	10AJ/212
(2)	Aerial, aircraft, Type 226	10B/16566
	<i>with</i>	
	Mounting Type 1031	10AJ/212
(16)	Switch, magnetic relay, Type S4	5C/3945
(15)	Switch, tumbler, Rotax, Type D5406 (VHF switch)	5C/4179
(17)	Switch, tumbler, Rotax, Type D5406 (SUPPLY switch)	5C/4179
(6), (8), (11), (13) (18), (19)	Block, terminal, Type B, 2-way	5C/430
	<i>(Note.—Terminal blocks (3), (4), (5), (20) and (29) are part of the main VHF installation)</i>	
—	Battery box Type 15 } <i>with</i> } Some installations only	10AP/189
	Mounting Type 1029 }	10AJ/210
General wiring		
(10)	Cable, electric, L.T. Unipren 4	5E/3037
(14)	Cable, electric, L.T. Unipren 6	5E/3038
(9)	Cable, electric, L.T. Uniprenmet 4	5E/3089
(12)	Connector, Type (Duvinmet small, 16, 5E/2932)	
(7)	Connector Type (Sextovinmet small, 2.5, 5E/2879)	

Chapter 4

TRANSMITTER-RECEIVER TYPE TR2002A

LIST OF CONTENTS

	<i>Para.</i>
<i>Introduction</i>	1
<i>Circuit changes</i>	2
<i>Servicing</i>	3
<i>Fault diagnosis</i>	5

LIST OF ILLUSTRATIONS

	<i>Fig.</i>
<i>Circuit diagram of TR2002A, showing wiring changes</i>	1

Introduction

1. In the design of transmitter-receiver Type TR2002 no provision was made for the use of the speech amplifier and modulator for intercommunication (I/C). With the transmitter-receiver Type TR2002A (Ref. No. 1OD/122941) this is accomplished by using transmitter-unit Type 98A (Ref. No. 1OR/149). This unit enables the speech amplifier and modulator to be used for I/C purposes when the equipment is switched to "receive". The wiring changes between the transmitter units Type 98 and 98A are not great and are simplified by the introduction of a relay unit, having four contacts, which is substituted for the existing changeover relay. The facility of I/C can be switched in or out by transferring the I/C selector screw, located on the panel at the top of the relay box, from one position to a second position. An additional fuse 1FS3 has been fitted for the protection of the h.t. supply to the audio section.

WARNING...

The I/C selector screw on the selector panel is at h.t. potential, and the equipment must be switched off before transferring the screw from the I/C OFF position to the I/C ON position. After adjustment the screw should be locked in position using the approved varnish to prevent it from loosening under vibration.

Circuit changes

2. The circuit of the transmitter unit Type 98A is similar to that of the transmitter unit Type 98 with the exception of the connections of the h.t. supply to the speech amplifier, modulator, power amplifier and receiver audio amplifier (*fig. 1*). The differences are as follows:—

(1) The h.t. connection from the receiver audio amplifier is removed from the unfused h.t. rail, and is rewired to the rail via fuse 1FS3, which is an additional item in TR2002A.

(2) A connection from the anode of power amplifier valve (1V8) to the modulation transformer (1TR2) is taken via relay contacts 1SR/4; these contacts are open on "receive" and closed on "transmit".

(3) Wired to the centre terminal of the I/C selector panel is the h.t. connection from the speech amplifier and modulator. In the I/C ON position it is connected to the h.t. rail via the I/C selector screw, an outer terminal of the selector panel, and fuse 1FS3. In the I/C OFF position it is connected to the h.t. rail via the I/C selector screw, the other outer terminal of the selector panel, fuse 1FS1 and a pair of contacts (SR3) on relay 1SR/4. These contacts are open on "receive" and closed on "transmit".

(4) The h.t. connection from the screen grids of the modulator valves (1V3 and 1V4) to the modulation transformer centre tap is taken via the 470K resistor 1R28. A pair of contacts (SR1) on relay 1SR/4 are arranged to short-circuit this resistor when the equipment is switched to transmit, maintaining the output of the modulator substantially constant in the receive and transmit conditions.

Servicing


3. In transmitter-receiver Type TR2002 only two fuses 1FS1 and 1FS2 are fitted. With transmitter-receiver Type TR2002A it was found necessary to include an additional fuse 1FS3, and one of the original spare fuse holders was used for this purpose. This fuse safeguards the h.t. supply line to the audio section. Should any of these fuses fail, the cause should be ascertained before a new one is fitted. The fuses used are Type 153 (Ref. 10H/18680) and are housed in the fuseholders Type 102 mounted on the front panel of the transmitter-receiver. To renew a fuse, procedure in Part 2, Chap. 1, para. 14 should be followed.

RESTRICTED

PART 2

SERVICING

RESTRICTED



PART 2
SERVICING

LIST OF CHAPTERS

Note.—A list of contents appears at the beginning of each chapter

- 1 General servicing**
- 2 Tuning the transmitter and receiver (~~to be issued later~~) *1/69***
- 3 IF alignment (~~to be issued later~~) *1/28***

Chapter I

GENERAL SERVICING

LIST OF CONTENTS

	Para.		Para.
Introduction	1	Fuses	14
Precautions	2	Valves	15
Test bench connectors and junction box	5	Relays	17
Renewing the batteries	7	Preset controls	20
Dismantling and assembling the transmitter-receiver	8	Rotary transformer	21
Component location	12	Effect of servicing on the tuning and alignment of TR.2002	37
Cleaning	13		

LIST OF TABLES

	Table
Connector set ARI.18041, bench testing	1
Valves used in transmitter-receiver Type TR.2002	2

LIST OF ILLUSTRATIONS

	Fig.		Fig.
Transmitter-receiver Type TR.2002, dismantling	1	Battery box Type 15	4
Junction box Type 170, general view	2	Rotary transformer Type 119	5
Junction box Type 170, circuit	3		




Fig. 1. Transmitter-receiver Type TR.2002, dismantling

RESTRICTED

(A.L.14, Apr. 56)

Introduction

1. This chapter is to provide guidance regarding the general servicing of transmitter-receiver Type TR.2002. Instructions regarding the tuning and alignment of the equipment are given in Chapter 2 and 3, respectively, of this Part, and the locating of possible faults in the equipment are dealt with in Part 3.

Precautions

2. For the majority of servicing operations the case must be removed from the transmitter-receiver. Normally the power supply should be switched off or (preferably) disconnected while the equipment is in this condition, but for some operations and tests it is necessary to operate the equipment with the case removed. In these instances, due care must be exercised to avoid the risk of electrical shock, and also to avoid the possibility of the exposed wiring being short-circuited.

3. If the equipment is to be switched on for test purposes, first ensure that the transmitter and receiver are electrically interconnected through the normal plugs and sockets, and that all valves are in place. This is necessitated by the series parallel type of heater circuit employed. Where additional freedom is required for handling the units separately on the bench, the six-inch extension leads of connector set Type ARI.18041, bench testing (if available) may be interposed between the normal plugs and sockets.

4. Even minor items of servicing, such as changing valves, may affect the alignment of the equipment, and consequently, unless good reason exists to the contrary (e.g. need for renewal) any valves which are removed for testing or similar purposes should be returned to their original positions in the transmitter-receiver. Para. 37 and 38 provide an indication of the extent of retuning or re-alignment necessary subsequent to certain servicing operations.

Test bench connectors and junction box

Connector set ARI.18041, bench testing

5. The above connector set (Res. W.T.42854) has been designed to facilitate the servicing of transmitter-receiver Type TR.2002. It consists of five connectors as listed below, and is used in conjunction with a box, junction, Type 170 (para. 6).

Junction box Type 170

6. Junction box Type 170 (Stores Ref. 10D 19216) is used in conjunction with the above connector set for the bench-testing of transmitter-receiver Type TR.2002. It consists of a case approximately 3 3/8 in. x 1 7/8 in. x 2 3/4 in., one six-pole plug, one mic./tel. jack, two toggle switches, and the appropriate wiring. The six-pole plug is mounted on the back of the case and, when in use, is connected by item 1 of the above connector set to the CONTROL plug on the front panel of the transmitter-receiver. The jack is mounted on the centre front of the case, and serves to connect the microphone and telephones to the transmitter and receiver units. The toggle switches are mounted on the front of the case, one on either side of the jack, and function as starting switch and send/receive switch, respectively. Fig. 3 shows the internal wiring of the box, and its general appearance is indicated in fig. 2.

Renewing the batteries

7. The batteries are housed in a battery box Type 15 (fig. 4). To change the battery, unscrew the large knurled captive nut visible on the top




Fig. 2. Junction box Type 170, general view

TABLE I
Connector set ARI.18041, bench testing

Item No.	Type No.	Stores Ref. No. IOHA/	Length		Type of cable	Sleeve markings		No. off
			ft.	in.		End "A"	End "B"	
1	B23/30A/6	13058	5	0	—	Control	Mic/tel	1
2	B2/50E/1	13059	5	0	—	TR.2002	Supply	1
3	D243/51E/3	14566	0	3	Uniradio 43	Supply	2PL1	1
4	10104	14567	0	6	—	1SK2	2PL4	1
5	D267/31A/1	13061	5	0	Uniradio 67	1PL6	Wattmeter	1

RESTRICTED




Fig. 3. Junction box Type 170, circuit

of the box and lift off the lid. The case will be seen to contain two 12-volt accumulators (*Stores Ref. 5J/3307*) connected in series, and each provided with a simple carrier. Unscrew the accumulator terminals and remove the two leads which connect to the output socket at the front of the box, also the short link which provides the series connection between the accumulators. Lift the accumulators from the box by means of the carriers, then transfer the carriers to the replacement accumulators. Insert the replacement accumulators in the box with the terminals towards the centre, connect them in series by means of the short link provided, and connect the red and black output leads to the appropriate terminals of the accumulators. Re-install the lid, and secure it with the large knurled nut. If it is desired to check the voltage of the accumulators without opening the box, this may be done at the terminal block mounted beside the output plug on the box front.

Dismantling and assembling the transmitter-receiver

8. In most instances the equipment is assembled by essentially a reversal of the dismantling procedure, and consequently no separate instructions are given.

To remove the transmitter-receiver from the case

9. With the power supply switched off or disconnected, unscrew the two coin-slotted captive screws at the rear of the case; then hold the case and withdraw the transmitter-receiver by means of the handle on the front panel.

To remove the receiver unit from the transmitter unit (fig. 1)

10. (1) Unscrew the locking ring of the receiver coaxial socket 1SK3 and withdraw it from the plug 2PL1 on the receiver chassis.
- (2) Disconnect the 8-pole socket 1SK2 from the plug 2PL4 on the receiver chassis.
- (3) Loosen the single captive screw which secures the rear mounting plate.
- (4) While supporting the receiver chassis, unscrew the four captive screws on the front panel (the four screws nearest the top of the panel).
- (5) Disengage the rear mounting plate from the transmitter and receiver chassis, and remove the receiver chassis, being careful to avoid damaging the components on its under side

by contact with the transmitter chassis or other objects.

Note . . .

When reassembling the transmitter-receiver, ensure that the opening in the rear mounting plate is in line with the air intake of the rotary transformer.

Transmitter unit

11. It is unnecessary to detach the transmitter chassis from the front panel, as all components are readily accessible when the receiver chassis is removed.

Component location

12. By reason of the small size of the components used in the transmitter-receiver, it has not proved possible to provide all components with identification markings. The larger components are so marked, and reference to the circuit and component-location diagrams in Part 1, Chap. 2 should facilitate the location of the smaller items.

Cleaning

13. As noted earlier, care is necessary to avoid damage to the components, or movement of components or wiring which might affect the performance or alignment of the units. For this reason it is usually best to restrict cleaning of the chassis to the careful use of an air blower.

Fuses

14. Only two fuses, 1FS1 and 1FS2 are included in the actual transmitter-receiver. Fuse 1FS1 is connected in the transmitter, and fuse 1FS2 in the receiver HT supply circuits, both fuses being rated at 250mA. Should either of these fuses fail, the cause should be ascertained before a new one is fitted (*Part 3, Chap. 1* suggests possible causes). The fuses used are Type 153 (*Stores Ref. 10H/18680*) and are housed in two fuseholders Type 102 mounted on the front panel of the transmitter-receiver. Two similar fuseholders are provided on the front panel to contain spare



Fig. 4. Battery box Type 15

(A.L.7, Mar. 54)

fuses. To renew a fuse, unscrew the fuseholder cap, withdraw the expended fuse, insert the new one, and screw the cap home.

Valves

15. The valves fitted in this transmitter-receiver are of the miniature, glass-based type. They are each enclosed in a screening can which is secured by a bayonet catch. To remove a valve, press the can downward, turn it counterclockwise and lift it off, then withdraw the valve from its holder preferably using extracting tool Ref. Z970289. The valve should be drawn straight from the holder, as rocking the valve will result in the valve pins being distorted, and could produce air leakage at the pins. If the screening cans are to be removed, note that the cans fitted to the CV850 valves (2V1, 2V2, 2V8 and 2V9) are shorter than those fitted to the remainder of the receiver valves, and are not interchangeable with them. Note also that the cans for the CV2135 valves (1V1 and 1V2) are larger in diameter than those for the remainder of the transmitter valves.

16. Table 2 lists the valves to be used in transmitter-receiver Type TR.2002. Before installing any valve, make certain that the pins are in correct alignment, using the special valve pin adjusting tools as necessary.

TABLE 2

Valves used in transmitter-receiver Type TR.2002

Valve number on circuit diagrams	Function	CV No
1V1, 1V2	Speech amplifier	2135
1V3, 1V4	Modulators	416
1V5	Oscillator and frequency trebler	416
1V6, 1V7	1st and 2nd frequency doublers	416
1V8	Power amplifier	416
2V1	RF amplifier	850
2V2	Frequency changer	850
2V3, 2V4, 2V5	1st, 2nd, 3rd IF amplifiers	131
2V6	Detector and AGC delay	140
2V7	AF amplifier	138
2V8	Oscillator and frequency quadrupler	850
2V9	Frequency doubler	850

Note . . .

When certain valves are changed it will be necessary to retune or re-align the unit affected. An indication of the action necessary is given under the heading "Effect of servicing on the tuning and alignment of TR.2002".

Relays

17. The relays used in this transmitter-receiver should require little servicing, and by reason of the easily-damaged nature of the contacts and the difficulty of making accurate adjustments without special equipment, these items should not normally be interfered with. If it becomes necessary to clean the contacts this may be done using a small amount of carbon-tetrachloride, but any required servicing in excess of this should be considered as being third-line.

18. The send/receive relay is mounted on the back of the front panel, immediately below the aerial plug. The rear end of the plug and the relay are each enclosed in a separate compartment of a small screening box. Access is by unscrewing a knurled captive nut and pulling the cover straight off (*fig. 1*).

19. The starter relay, which controls the power supply to the valve heaters and the rotary transformer, is mounted in the transmitter chassis immediately below the front end of the rotary transformer. It is enclosed in a plastic cover which cannot be removed while the relay is in the transmitter. The relay is secured to the chassis by two screws and locknuts, the screw heads being visible below the choke located at the forward end of the rotary transformer; it may be necessary to remove the choke to obtain access to these screws.

Preset controls

20. The preset capacitor 1C24 which tunes the power amplifier stage of the transmitter is locked by a small screw located near the capacitor spindle and visible on the top of the chassis. This screw must be loosened before adjusting the capacitor and tightened after adjustment. The remainder of the preset controls of the transmitter and receiver units have friction sufficient to prevent their accidental movement, while at the same time permitting the necessary adjustments to be made. As a result of this, no locking or unlocking action is necessary either before or after adjustment of these controls. Note in particular that the large conical nut on the receiver preset gain control must not be interfered with, as it serves to secure the control to the chassis. The fact that the friction device is housed in this nut is purely incidental; no provision is made for the adjustment of the degree of friction. The tuning slugs of the IF transformers are secured against accidental movement by an initial application of a silicone sealing compound (Admiralty Pattern 7003). This compound, while being adequate to prevent the accidental movement of the slugs, is non-setting, and consequently requires no softening treatment before the adjustment is made. The application of additional compound should not be necessary except in special circumstances, *e.g.* when a new tuning slug is fitted. If a new slug is to be fitted, the compound should be worked well into the threads of the slug, and a little applied to the interior of the coil former so that it will be carried well into the threads when the slug is inserted.

Rotary transformer

21. The rotary transformer used with this equipment is Type 119 (*Stores Ref. 5UB/5908*). It operates on an input power supply of 21 to 29 volts. At the rated input of 26 volts it provides an HT output of 170 volts while supplying a current of approximately 90mA. As illustrated in *fig. 5*, it is installed on an anti-vibration mounting at the rear of the transmitter chassis.

Access to commutators and brush gear

22. For access to the rotary transformer, first remove the receiver chassis, as described in para. 10. It will now be seen that no cover is

provided at the front (or output) end of the rotary transformer. The cover at the rear (or input) end is secured by two hairpin-type clips, one at the top and one at the bottom of the cover, which engage with studs on the body of the machine.* To remove the cover, release both clips, making certain that the lower one does not foul the wiring, then draw the cover straight off. When refitting the cover, ensure that the input leads to the brush boxes are accommodated in the two small slots in the lower half of the cover, that both clips are properly engaged, and that the cover is correctly seated against the flange of the rotary transformer, so that it does not foul the impeller vanes. This is important, as even a slight interference between the impeller and its cover could result in damage to the impeller, damage to the bearings, and overloading of the rotary transformer with consequent sparking at the brushes and the production of RF interference. If brushes are to be renewed it will be necessary to remove the rotary transformer from the chassis.

To remove the rotary transformer from the chassis

23. To remove the rotary transformer from the chassis, first remove the four screws which secure the earthing braid and the rotary transformer clamping band to the anti-vibration mounting (fig. 5); then move aside the earthing braid while holding the rotary transformer to avoid risk of damage to the wiring. The rotary transformer may now be gently raised a little, the end cover taken off, and the screws securing the wiring tags to the terminal extension lugs (below the brushes) removed. The terminal extension lugs must be supported when disconnecting the leads, as unsupported pressure may cause permanent damage. The rotary transformer is now entirely free of the chassis and may be removed. The wiring tag screws should be replaced in position to avoid loss. With the possible exceptions of the renewal of brushes or impellers, the machine may not, on any account, be further dismantled at second-line servicing.

Examination of the rotary transformer

24. When servicing the rotary transformer, both commutators should be examined for traces of arcing, burning or discolouration. The track portion of each commutator should be of a uniform colour between light chocolate and dark grey, the brush track on the output commutator being normally slightly darker than that on the input commutator. If there are traces of local burning, or if blackened segments occur at regular or irregular intervals, reference should be made to Part 3, Chap. 1, Table 3 which indicates possible causes of these symptoms. If the damage is in excess of that dealt with in the subsequent paragraphs, or if a rotary transformer requires servicing in excess

* On later rotary transformers the cover may be secured by four screws.




Fig. 5. Rotary transformer Type 119

of the facilities available at the user unit, a replacement machine should be fitted and the removed one returned to the appropriate Maintenance Unit.

Commutators

25. Commutators which are dirty (as distinct from worn, pitted or burnt) may be cleaned using a piece of clean cloth moistened with unleaded petrol. Care should be taken to restrict the petrol to the area being cleaned, and time should be allowed for all petrol to evaporate before the machine is again switched on. No grease or oil of any kind may be permitted on the commutator or brushes, and contamination of the surface with the fingers must also be avoided. In no instance may abrasives of any kind be used for cleaning the commutators. Should the commutators require servicing in excess of the above, the machine must be returned for third-line servicing.

Brushes

26. When re-installing a brush which has been removed for examination or any other reason, it is essential that it be returned to its original holder and to its original orientation in the holder. If this is not done the brush will not bed properly on the commutator.

27. If excessive sparking occurs at the brushes they should be removed and examined for wear, for freeness in the holder, and for satisfactory bedding on the commutator. In this machine the brushes should normally be renewed when worn for more than one quarter of their length, as continued use after this stage has been reached may result in unsatisfactory operation due to the reduced spring pressure.

28. If a brush shows signs of sticking in its holder, the holder should be cleaned with unleaded petrol. If this does not produce the desired result, the sides of the brush may be carefully smoothed with grade 000 glasspaper, being careful to remove the

(A.L.7, Mar. 54)

Chapter 2

TUNING THE TRANSMITTER AND RECEIVER

LIST OF CONTENTS

	Para.		Para.
Introduction	1	Tuning receiver unit Type 127	5
Preliminary operations	2	Adjustment of receiver AF gain control	7
Tuning transmitter unit Type 98	3	Typical meter readings	9

LIST OF TABLES

	Table
Typical meter readings at test plugs	1

LIST OF ILLUSTRATIONS

	Fig.		Fig.
Transmitter tuning controls	1	Receiver tuning controls	3
Test bench layout for transmitter tuning	2	Test bench layout for receiver tuning	4

Introduction

1. The transmitter and receiver are normally correctly aligned and tuned when received from the factory, and should require no adjustment before being put into service. A few units may be supplied without crystals, but these units are also pretuned, and it should only be necessary to insert the correct crystals. Should it be found necessary to retune any unit, the methods detailed in the subsequent paragraphs may be applied.

Note . . .

The operations described in this chapter should be performed only by authorized personnel, and where suitable test equipment is available. Specific test equipment is listed in the following paragraphs, but the methods described may be applied using approved alternative equipment. The meter readings quoted in this chapter assume an input power supply of exactly 24V.

Preliminary operations

2. (1) With the power supply switched off or disconnected, unscrew the two coin-slotted screws at the rear of the case, and remove the case.




Fig. 1. Transmitter tuning controls

(2) Place the transmitter-receiver in a position where the trimming capacitors are accessible and there is no risk of the exposed wiring being accidentally short-circuited. The receiver unit may be tuned when installed on the transmitter unit, but must be removed to provide access to the power amplifier tuning capacitor locking screw if the transmitter is being tuned.

WARNING

When operating the equipment with the case removed, care must be taken to avoid the possibility of electrical shock from the exposed wiring.

Tuning transmitter unit Type 98

3. The following equipment is required:—

	Stores Ref.
Milliammeter 0-1 (75 ohms)	5Q/11843
<i>or</i>	
Testmeter Type 26	10S/16401
Wattmeters, VHF, CT87	10S/16415
<i>or</i>	
Test set X740A (when available)	
Connector set ARI.18041, bench testing (Chap. 1)	
Box, junction, Type 170	10D/19216

4. Proceed as follows:—

- (1) Connect wattmeter, VHF, CT87 to the AERIAL plug on the front panel (connector, 10HA/13061), the power supply to the BATTERY plug (connector 10HA/13059), and the other associated items of equipment, (junction box, telephones and microphone) to the CONTROL plug (connector 10HA/13058). Insert the correct crystal (10X/ZDH/10125 Kc/s) if this has not already been done.
- (2) Switch on the power supply and permit the equipment to warm up. Set the TRANSMIT/RECEIVE switch on the junction box to TRANSMIT.

- (3) Check the RF voltage across the crystal by connecting the 0-1 milliammeter to test plug 1PL5/3. The voltage should not exceed 15V RMS, as indicated by a meter indication of 150 microamp. Should a reading in excess of this be obtained, try changing valve 1V5 and/or the crystal.
- (4) Connect the meter to test plug 1PL4/3 (in the grid circuit of the first frequency-doubler valve, 1V6) and, using a non-metallic tool, adjust trimming capacitor 1C10 for maximum meter indication.
- (5) Connect the meter to test plug 1PL4/2 (in the grid circuit of the second frequency-doubler valve, 1V7) and adjust trimming capacitor 1C15 for maximum meter indication.
- (6) Connect the meter to test plug 1PL4/1 (in the grid circuit of the power amplifier valve, 1V8) and adjust trimming capacitor 1C20 for maximum meter indication.
- (7) Loosen the small-locking screw visible on top of the chassis adjacent to the spindle of the trimming capacitor 1C24, then adjust the capacitor for maximum output as indicated by wattmeter CT87, and tighten the locking screw.
- (8) The unmodulated output, as indicated by the wattmeter CT87 connected to the AERIAL socket, should exceed 1W (i.e., 1W into a 45-ohm resistive load).
- (9) The modulation may be checked by speaking into the microphone; sidetone should be audible in the telephones.

Note . . .

Table 1 shows typical readings as obtained at the test plugs.

Tuning receiver unit Type 127

5. The following equipment is required:—

	Stores Ref.
Signal generator Type '62	10S/16318
or	
*Signal generator Type 31	10S/66
Microammeter 0-100	5Q/19854
or	
Testmeter Type Y	10S/16379
Connector set, Type ARI.18041, bench testing (Chap. I)	
Box, junction, Type 170	10D/19216

Note . . .

*If the signal generator Type 31 is used, the output terminating unit should be modified by connecting a 33-ohm ± 10 per cent, $\frac{1}{2}$ watt resistor, insulated, grade II, between the 14 ohms insulated terminal and the centre pin of the end portion only of socket ref. Z56044. Also, a connection should be made from the earth terminal to the outer of the socket. It is essential that the connecting wires shall not exceed $\frac{1}{2}$ in. in length.




Fig. 2. Test bench layout for transmitter tuning

6. Proceed as follows:—

- (1) With the transmitter-receiver removed from the case and the power supply, junction box, and telephones connected as in para. 4, insert the crystal (10X/ZDH/13972.5 Kc/s) if this has not already been done, then switch the equipment ON, set the TRANSMIT/RECEIVE switch to RECEIVE, and permit the set to warm up.
- (2) Check the RF voltage developed across the crystal by connecting the microammeter to test plug 2PL2/2. The voltage should not exceed 10V RMS, as indicated by a meter reading of 85 microamps. Should a reading in excess of this figure be obtained, try changing the oscillator valve (2V8) and/or the crystal.
- (3) Connect the microammeter to test plug 2PL2/3 (in the grid circuit of the frequency-doubler valve, 2V9) and adjust trimming capacitor 2C49 for maximum meter indication.
- (4) Adjust the signal generator for an output frequency of 121.5 Mc/s modulated to a depth of 30 per cent at 1,000 c/s.
- (5) Apply the output of the signal generator to the AERIAL plug of the transmitter-receiver (connector 10HA/13061 of the connector set may be used), and connect the microammeter to test plug 2PL3 (in the detector diode circuit).

Note . . .

While the undernoted tuning operations are being performed, the signal generator output should be adjusted to keep the diode current, as indicated by the microammeter, below 30 microamps, ensuring at the same time that the signal generator is tuned to give a peak diode current at each stage of alignment. This is necessary, as a number of factors, including the necessity for adjusting the signal generator attenuator, may slightly affect the output frequency of the signal generator.

RESTRICTED

- (8) Adjust the signal generator to 102.06 Mc/s.
- (9) With the above frequency applied to the aerial plug, adjust trimming capacitor 2C1 (the second-channel rejection trimmer) for maximum dip, increasing the signal generator output as necessary while doing so. To produce a 30 microamp indication on the meter, the signal generator output required should be at least 50dB greater than that required at operation (7).
- (10) When tuning has been satisfactorily performed, switch off the transmitter-receiver, disconnect the test equipment, and re-install the transmitter-receiver in its case.

Note . . .

Table 1 shows typical meter readings as obtained at the test plugs.

Adjustment of receiver AF gain control

7. Equipment required:—

Signal generator Type 62	Stores Ref. 10S/16318
Microammeter 0-100	5Q/19854
<i>or</i>	
Test meter Type Y	10S/16379

Output meter Type 2 10S/11934
 Connector set Type ARI.18041,
 bench testing (*Chap. I*)
 Box, junction, Type 170 10D/19216

8. Proceed as follows:—

- (1) With the transmitter-receiver removed from the case and connected to the bench installation as in para. 6, connect the microammeter to plug 2PL3 (in the detector diode circuit), and connect the output meter Type 2 across the \pm leads of a mic/tel connector plugged into the junction box Type 170.
- (2) Adjust the signal generator for an output at 121.5 Mc/s with 70 per cent modulation at 1,000 c/s. Apply this output to the aerial socket of the transmitter-receiver, and adjust the signal generator attenuator to produce a diode current indication of 30 micro-amp.
- (3) Adjust the preset AF gain control of the receiver to produce an output of 50 milliwatt into 150 ohms, as indicated on the output meter Type 2.

Note . . .

The gain control is self-locking, consequently no locking or unlocking action is necessary before or after adjustment.

Typical meter readings

9.

TABLE I
Typical meter readings at test plugs

Test plug	Circuit	Typical reading (microamps)	Remarks
Transmitter			
1PL4/1	1V8, grid circuit	750	
1PL4/2	1V7, grid circuit	550	
1PL4/3	1V6, grid circuit	250	
1PL5/1	1V3, 1V4, anode circuit	120	
1PL5/2	1V8, anode circuit	200	
1PL5/3	1V5, grid circuit	120	This represents 12V RMS across the crystal. Reading is not to exceed 150 microamp.
Receiver			
2PL2/1	2V1, cathode circuit	75	With no signal applied
2PL2/2	2V8, grid circuit	80	Must not exceed 85 microamp
2PL2/3	2V9, grid circuit	50	
2PL3	2V6A, detector diode circuit	—	A diode current of 30 microamp should be obtained with a RF input of not greater than 10 microvolt

Note . . .

The above readings were taken with an input power supply of exactly 24V, and using the specified 0-1 milliammeter for all transmitter measurements and the 0-100 microammeter for all receiver measurements. Changes in the input voltage applied or in the test equipment used may cause differences in the readings. Except where limits are given in the above table, the figures quoted should be regarded as being for guidance only, as the readings will vary in different equipments.

Chapter 3

IF ALIGNMENT

LIST OF CONTENTS

	Para.		Para.
Introduction	1	IF alignment and bandwidth adjustment	4
Equipment required	2	Adjustment of audio gain control	5
Calibration of signal generator incremental scale	3	Operations after alignment	7

LIST OF ILLUSTRATIONS

	Fig.		Fig.
Typical form of calibration diagram for signal generator incremental tuning control	1	Receiver unit Type 127, tuning and test points for IF alignment	2
		Test bench layout for IF alignment	3

Introduction

1. The IF alignment and bandwidth adjustment operations detailed below will normally be performed at third-line servicing only. The incremental scale of the signal generator must be calibrated before it is used for the bandwidth measurements; para. 3 provides instructions for this operation. Once performed, the calibration should hold good for a considerable time; it should, however, be checked at reasonable intervals, say, once per month, to ensure that accuracy is maintained.

Equipment required

2. The following equipment is required:—

Signal generator Type 56	Stores Ref. 10S/647
or	
Signal generator Type 57	10S/695
Microammeter 0-100	5Q/19854
or	
Test meter Type Y	10S/16379
Frequency meter set SCR-211-M (or one of the SCR-211 series)	
Connector set Type ARI.18041, bench testing (<i>Chap. 1</i>)	
Box, junction, Type 170	10D/19216

Calibration of signal generator incremental scale

3. To obtain accurate bandwidth measurements it is necessary to calibrate the incremental scale of the signal generator. This may be done, using frequency meter SCR-211-M as described below:—

- (1) Set up the frequency meter, then set the FREQUENCY control of signal generator Type 56 to 9.72 Mc/s with the INCREMENTAL TUNING control at zero, and connect its output to the frequency meter as described in A.P.2538HA, Vol. 6, Part 2, Sect. 2, Chap. 3.
- (2) Rotate the INCREMENTAL TUNING control of the signal generator clockwise to +5 divisions, then rotate the tuning control of the frequency meter clockwise until a zero beat is obtained in the telephones (plugged into the frequency meter), and note the frequency meter dial reading. Proceed in this manner for every

- five divisions of the INCREMENTAL TUNING control, i.e., for +10, +15, +20, and so on to +50 divisions.
- (3) Return the INCREMENTAL TUNING control of the signal generator to the zero position.
 - (4) Rotate the INCREMENTAL TUNING control of the signal generator counter-clockwise to -5 divisions, then rotate the tuning control of the frequency meter counter-clockwise until a zero beat is obtained, and note the dial reading. Proceed in this manner for every five divisions of the INCREMENTAL TUNING control, i.e., -10, -15, -20, -25 and so on to -50 divisions.
 - (5) Convert the frequency meter dial readings obtained to frequencies, using the calibration charts provided with the frequency meter. It will be necessary to interpolate if the dial readings fall between two calibration points on the chart. List the frequencies in terms of

INCREMENTAL SCALE SETTING (DIVS)	-20	-15	-10	-5	0	+5	+10	+15	+20
FREQUENCY (Kc/s)	-72	-54	-36	-18	0	+18	+36	+54	+72




Fig. 1. Typical form of calibration diagram for signal generator incremental tuning control

(A.L.14, Apr. 56)

kilocycles above and below 9.72 Mc/s, as indicated in fig. 1.

- (6) Plot a graph of \pm kc/s against divisions of the INCREMENTAL TUNING scale in the form indicated in fig. 1.
- (7) The signal generator INCREMENTAL TUNING scale having been calibrated, proceed with the IF alignment as follows:—

IF alignment and bandwidth adjustment (fig. 3)

4. (1) With the input power supply switched off or disconnected, remove the transmitter-receiver from the case.
- (2) Remove the receiver from the front panel (*Chap. 1, para. 10*).
- (3) Position the receiver chassis so that both sides are accessible, and connect sockets 1SK2 and 1SK3 of the transmitter to plugs 2PL4 and 2PL1 of the receiver by means of the six-inch extension leads of the connector set (Ref. 10HA/14567 and 10HA/14566, respectively).
- (4) Connect the 24V supply to the BATTERY plug using connector Ref. 10HA/13059, and the remaining items of the bench installation (junction box Type 170, telephones, and microphone) to the CONTROL plug on the front panel by means of connector Ref. 10HA/13058).
- (5) Remove the receiver crystal, and connect the microammeter to plug 2PL3 at the rear of the receiver chassis (*fig. 2*). When connected in this position the meter provides an indication of the detector diode current.
- (6) Adjust the signal generator to produce an unmodulated output at 9.72 Mc/s frequency with the INCREMENTAL TUNING control at zero.
- (7) Connect the earthy side of the signal generator output to the receiver chassis, and the other side to the grid of the frequency-changer valve 2V2 through a 0.1 microfarad shielded capacitor. A length of Uniradio 42 and the spare cable connector (10A/17695) from the signal generator should be used as the signal generator output connector.
- (8) Switch on the transmitter-receiver and the signal generator, and permit them to warm up. Set the TRANSMIT/RECEIVE switch on the junction box Type 170 to RECEIVE.
- (9) Adjust the signal generator output to produce a 30 microamp indication on the meter connected to 2PL3.
- (10) Using a non-metallic tool, adjust the primary and secondary tuning slugs of the IF transformers for maximum output, and at the same time adjust the signal generator output as necessary to maintain the meter indication at the 30 microamp level.

Note . . .

The tuning slugs are secured against accidental movement by an application of a silicone




Fig. 2. Receiver unit Type 127, tuning and test points for IF alignment

sealing compound (Admiralty Pattern 7603) This compound is non-setting, and consequently no action is necessary before adjusting the slugs. Unless a slug is to be renewed no additional sealing should be necessary on completion of tuning.

- (11) Increase the signal generator output by 6dB (i.e., by two times); the microammeter will now indicate, say, 40 microamp.
- (12) Increase the frequency of the signal generator output (using the INCREMENTAL TUNING control) until the microammeter again indicates 30 microamp, and note the frequency setting of the control.
- (13) Decrease the signal generator output frequency below 9.72 Mc/s by means of the INCREMENTAL TUNING control until the meter again indicates 30 microamp, and note the frequency setting. Convert the incremental scale readings obtained at (12) and (13) to Kc/s by means of the calibration graph. The difference between the two settings gives the bandwidth at 6dB down.
- (14) The bandwidth as ascertained above should be not less than 70 kc/s (35 kc/s above, and 35 kc/s below 9.72 Mc/s).
- (15) Should the bandwidth at 6dB down be unsymmetrical to the extent that the conditions at (14) are not met, it should be corrected by detuning the primary of the first IF transformer 2TR1 (the primary tuning slug is at the top end of the transformer). If the bandwidth is wide on the +ve side, screw the slug in; if wide on the -ve side, screw the slug out.
- (16) Set the signal generator for an output frequency of 9.72 Mc/s with the incremental tuning control at zero, and adjust the output to produce a 30 microamp indication on the meter connected to 2PL3. Note the signal generator output required, and increase it by 40dB (i.e., by 100 times). This will produce a meter indication of about 80 microamp.
- (17) Using the INCREMENTAL TUNING control, increase the signal generator frequency until the meter indication falls to 30 microamp, and note the reading on the incremental scale. Decrease the frequency below 9.72

Mc/s until the meter again indicates 30 microamp, and again note the reading on the incremental scale. The difference between the two readings (when converted to kc/s) will be the bandwidth at 40dB down; it should not exceed 260 kc/s, i.e., 130 kc/s above and below 9.72 Mc/s.

Adjustment of the audio gain control

5. The following equipment is required:—

	<i>Stores Ref.</i>
Signal generator Type 56	10S/647
<i>or</i>	
Signal generator Type 57	10S/695
Microammeter 0-100	5Q/19854
<i>or</i>	
Testmeter Type Y	10S/16379
Output meter Type 2	10S/11934
<i>or</i>	
Multimeter electronic CT38	10S/16308
Connector set Type ARI.18041, bench testing (<i>Chap. 1</i>)	
Box, junction, Type 170	10D/19216

6. With the transmitter, receiver, microammeter, signal generator and junction box arranged as for IF alignment, proceed as follows:—

- (1) Connect the output meter across the Tel± leads of a mic-tel connector plugged into the junction box Type 170 (*fig. 3*).

- (2) Adjust the signal generator to give an output at 9.72 Mc/s with 70 per cent modulation at 1,000 c/s.
- (3) Adjust the signal generator output to produce a diode current indication of 30 microamp. If the equipment is in order and correctly aligned the signal generator output required should not exceed 300 microvolt.
- (4) Adjust the preset gain control of the receiver to produce an output of 50 milliwatt into 150 ohms, as indicated on the output meter.

Note . . .

An alternative method of adjusting the AF gain control is given in Chapter 2. This method makes use of a signal generator Type 62 or Type 61, the signal generator output (at 121.5 Mc/s with 70 per cent modulation at 1,000c/s) being applied to the AERIAL plug of the transmitter-receiver. This output is adjusted by means of the signal generator attenuator to produce a detector diode current indication of 30 microamp, and the receiver AF gain control is then adjusted to produce an output of 50 milliwatt into a 150 ohm load, as indicated on the output meter Type 2. If this method is to be applied, the crystal must first be inserted.

Operations after alignment

7. On completion of the adjustments, switch off, disconnect the test equipment, install the crystal, assemble the receiver unit on the transmitter unit, and install the complete transmitter-receiver in the case.





Fig. 3. Test bench layout for IF alignment

RESTRICTED

PART 3

FAULT DIAGNOSIS

RESTRICTED



PART 3

FAULT DIAGNOSIS

LIST OF CHAPTERS

Note.—A list of contents appears at the beginning of the chapter

I Fault diagnosis for transmitter-receiver Type TR.2002

Chapter I

FAULT DIAGNOSIS FOR TRANSMITTER-RECEIVER TYPE TR.2002

LIST OF CONTENTS

	Para.		Para.
Introduction...	1	Valve-base voltages	7
Preliminary operations	2	Defects in rotary transformer	8
Checking at test points	6		

LIST OF TABLES

	Table		Table
Fault diagnosis for the transmitter-receiver	1	Typical valve-base voltage measurements	3
Typical meter readings at test plugs	2	Rotary transformer defects	4

LIST OF ILLUSTRATIONS

	Fig.
Transmitter-receiver Type TR.2002, general view, showing test points	1

Introduction

1. This chapter provides information regarding the locating of faults which may occur in transmitter-receiver Type TR.2002. The circuit and component location diagrams appearing in Part 1, Chap. 2 should be referred to when performing the various tests suggested.

WARNING

For some tests it may be necessary to operate the equipment with the cover removed, and due care must be exercised to avoid the possibility of electrical shocks to the operator. The input power supply should be switched off or disconnected at all times except when the actual tests are being performed.

Preliminary operations

2. In the tables of defects and possible causes provided in this chapter it is generally assumed that the items of the installation external to the transmitter-receiver are in satisfactory condition, but before commencing to dismantle the equipment it is advisable to make a preliminary check, ensuring first of all that a suitable input supply is in fact available at the BATTERY plug on the front panel. If the motor generator fails to operate, the defect must be somewhere in the power input circuits of the transmitter (this includes the primary circuit of the rotary transformer) or in the starting circuit, which includes the ON-OFF switch, relay 1PO/1, and the associated wiring. If the motor generator operates, but the transmitter, the receiver, or both fail to operate, check first the 250mA fuses on the front panel. An overload in the transmitter unit is indicated if fuse 1FS1 has failed, and failure of fuse 1FS2 indicates an overload in the receiver unit. Should a fuse fail, the circuitry of the associated unit should be examined and the cause ascertained before a new one is fitted.

3. When the transmitter-receiver is removed from the case for further investigation it is usually advisable to make a rapid visual examination of the units for traces of mechanical damage, loose connections, valves, crystals or plugs incorrectly seated in their holders, gassy valves, and any other obvious signs of damage. If a unit is known to have been defective but appears to be in order when tested, tapping or gentle jarring of the chassis may reveal an intermittent or loose connection.

4. Even after the cover has been removed, access to many of the components is impossible so long as the transmitter and receiver are assembled together, and for any but the most obvious faults the receiver unit must be separated from the transmitter unit as described in Part 2, Chap. 1. The leads (terminated by sockets 1SK2 and 1SK3) which normally connect the transmitter to the receiver are of sufficient length to permit these two units to be connected when placed side-by-side on the bench. If greater freedom of access is desired, suitably terminated extension leads may be interposed between the transmitter and the receiver. The 6-in. extension leads (10HA/13060 and 10HA/13064) of connector set ARI.18041, bench testing, should be used if available.

Note . . .

It must be emphasized that, by reason of the series-parallel heater system used in this transmitter-receiver, it must not be switched on when the receiver unit is electrically disconnected from the transmitter unit, or when any of the valves are removed (the former restriction may not apply if special rigs become available for testing the units). Failure to observe these restrictions may result in damage to the equipment. Similarly, if valves are to be tested by substitution, the equipment should be switched off before making the changes.

RESTRICTED

(A.L.10, April 54)

TABLE I
Fault diagnosis for transmitter-receiver Type TR.2002

Symptom	Probable cause
Equipment does not operate	Open-circuit in external power supply circuit (check voltage at the BATTERY plug) Defective relay 1PO/1
Power supply is available at the BATTERY plug, but equipment does not operate	Defective rotary transformer (Table 4), or defective choke 1L1, 1L2
Valve heaters glow, but rotary transformer does not operate	Fuses 1FS1 and 1FS2 failed. Defective rotary transformer, defective relay 1SR/2, choke 1L3, or capacitor 1C1
Rotary transformer operates, but no HT on either transmitter or receiver	Defective relay 1SR/2. Fuse 1FS1 (transmitter) or fuse 1FS2 (receiver) failed. Possibly defect in the send-receive switch or the associated wiring
HT on transmitter, but not on receiver (or vice versa)	Defective valves. Contacts of relay 1SR1 damaged or misaligned
Low transmitter output	Check the associated circuit for continuity Short-circuit, or foreign matter between vanes of 2C49 Short-circuit between vanes of 1C20 Short-circuit between vanes of 1C15 Short-circuit between vanes of 1C10 Fuse 1FS2 failed. Defective AF valve 2V7. Defective resistor, capacitor or wiring associated with the AF stage. Defective transformer 2TR5 Fuse 1FS1 failed. If HT supply is reaching the transmitter, and the receiver is in order, absence of sidetone would indicate a failure in the transmitter speech amplifier or modulator stages Defective send/receive relay 1SR/2. Defective choke 1L5 or 1L6. Removed or defective transmitter crystal. Grid end of 1R13, 1R18, 1R22 or 1R26 may be shorting to the chassis. If sidetone is audible at the normal level, the indication is that the AF and modulator portions of the transmitter are in order. Check the oscillator, doubler and power amplifier stages at 1PL4/1, 2, 3 and at 1PL5/3; this should provide an indication of the defective stage Defective capacitor 1C28. Defective transformer 1TR2. Check the cathode potential of 1V1 and 1V2 for bias Examine 1C5 for broken or loose wire terminations 2C40 shorted
Low receiver sensitivity	
HT and LT supply to both units in order, but:—	
No reading on one or more test points	
No readings on test point 2PL2/3	
No readings on test point 1PL4/1	This indicates that the AF portion of the receiver is in order, and consequently the defect must be in the earlier stages. Check that the crystal is installed. Readings taken at the test points 2PL2/1, 2, 3 and 2PL3 will assist in locating the defect. See above for reasons for zero reading at these points. Check RF trimming capacitors for short-circuits or wrong adjustment
No readings on test point 1PL4/2	
No readings on test points 1PL4/3	
No carrier sound from receiver, and no sidetone audible in phones	
No transmitter sidetone or output to aerial, but receiver functions normally	
No transmitter output to the aerial, but receiver functions normally and sidetone is audible	
Severe modulation distortion in transmitter (distortion in sidetone)	
No sidetone audible but receiver functions normally and there is output from transmitter to aerial	
No signals received, but sidetone audible	
Intermittent output from receiver	
Receiver instability	This is usually caused by defective decoupling in the RF or IF portions of the receiver. If the instability ceases when the grid of the frequency-changer valve is earthed, the trouble lies in the RF portion, and all the associated 330 picofarad capacitors should be examined for loose or broken wire terminations. Similarly, if the fault appears to be in the IF portion examine the terminations of all the 0.01 microfarad capacitors in the IF strip

(A.L.10, April 54)

RESTRICTED

TABLE I—contd.

Symptoms	Probable cause
Receiver operates only on very strong signals	Defect in RF portion of receiver. Check valves and tuning
Excessive RF interference from rotary transformer	Defective earthing of rotary transformer case. Commutator or brush trouble (Table 4). Defective capacitors 2C44, 2C56, 2C57, 2C58, or 2C59.
Crackling noise in 'phones occurring only when the case is fitted	Defective case-earthing contacts on transmitter and or receiver chassis
Troubles not included in the above	Check the transmitter and receiver valve voltages (Table 3). Make continuity tests as necessary

Checking at test points

6. Where the fault is not immediately obvious, a rapid check of the meter indications obtained at the built-in test points, plugs 1PL4/1, 2, 3 and 1PL5/1, 2, 3 on the transmitter, and at plugs 2PL2/1, 2, 3 and 2PL3 on the receiver (fig. 1), and a comparison of the resulting readings with those given in Table 2 will provide an indication of the stage in which the fault occurs (the table indicates the circuits in which the various test points are inserted). A

milliammeter 0-1 (Stores Ref. 5Q 11843) or a testmeter Type 26 (Stores Ref. 10S 16401) should be used for the transmitter, and a microammeter 0-100 (Stores Ref. 5Q 19854) or testmeter Type Y (Stores Ref. 10S/16379) for the receiver tests. Table 1 provides some conclusions which may be drawn from the meter readings, but it must be borne in mind that the readings may vary considerably from set to set.

TABLE 2
Typical meter readings at test plugs

Test plug	Circuit	Typical reading (Microamps)	Remarks
Transmitter			
1PL4/1	1V8, grid circuit	750	
1PL4/2	1V7, grid circuit	550	
1PL4/3	1V6, grid circuit	250	
1PL5/1	1V3, 1V4, anode circuit	120	
1PL5/2	1V8, anode circuit	200	
1PL5/3	1V5, grid circuit	120	This represents 12V RMS across the crystal. Reading is not to exceed 150 microamp.
Receiver			
2PL2/1	2V1, cathode circuit	75	With no signal applied
2PL2/2	2V8, grid circuit	80	Must not exceed 85 microamp
2PL2/3	2V9, grid circuit	50	
2PL3	2V6a, detector diode circuit	—	A diode current of 30 microamp. should be obtained with an RF input at the AERIAL socket of not greater than 10 microvolt (for second line servicing the equipment may be accepted provided the RF input required does not exceed 20 microvolt)

Note . . .

The above readings were taken with an input power supply of exactly 24V, and using the test equipment specified in para. 6. Changes in the input voltage or in the test equipment used may cause differences in the readings. Except where limits are specified in the table, the figures quoted should be regarded as being for guidance only, as they may vary in different equipments.

Valve-base voltages

7. A check of the valve-base voltages and comparison with the typical values given in Table

3 will also be of assistance in locating the source of trouble. This series of measurements may be taken using the appropriate ranges of a test meter Type F. If the meter indication at any point is found to vary from the specified value by more than 10 per cent, the components involved in that portion of the circuitry should be investigated. When taking the measurements it must be borne in mind that the use of a meter of different sensitivity from that specified may produce readings differing considerably from those quoted. The voltage drop across the heater pins of any valve will be approximately one fourth of the input power supply voltage. If

the voltage drop across the heater pins of any valve is unexpectedly high or low, it is possible that one or more of the heaters is defective. If an excessive voltage drop is found across the heater pins of a valve, the probability is that that heater, or one of those in parallel with it, is defective. Conversely,

a lower than normal voltage drop would suggest a defective heater in one of the valves which are in *series* with that measured. The combined transmitter and receiver heater circuit is shown in Part 1, Chap. 2, Fig. 6.

TABLE 3
Typical valve-base voltage measurements

Valve reference on diagrams	CV. No.	Function	Pin No.	Element	Voltage
Transmitter					
1V1, 1V2	2135	Speech amplifiers	3	Cathode	1.2
			8	Second grid	30
			7	Anode	85
1V3, 1V4	416	Modulators	2	Cathode	12.4
			7	Second grid	158
			5	Anode	155
1V5	416	Crystal oscillator and frequency trebler	2	Cathode	0
			7	Second grid	65
			5	Anode	155
1V6	416	1st frequency doubler	2	Cathode	0
			7	Second grid	100
			5	Anode	155
1V7	416	2nd frequency doubler	2	Cathode	0
			7	Second grid	110
			5	Anode	155
1V8	416	Power amplifier	2	Cathode	0
			7	Second grid	115
			5	Anode	152
Receiver					
2V1	850	RF amplifier	2	Cathode	1.2
			6	Second grid	80
			5	Anode	150
2V2	850	Frequency changer	2	Cathode	4.0
			6	Second grid	100
			5	Anode	150
2V3, 2V4	131	1st and 2nd IF amplifiers	2	Cathode	1.3
			7	Second grid	130
			5	Anode	150
2V5	131	3rd IF amplifier	2	Cathode	1.5
			7	Second grid	145
			5	Anode	145
2V6	140	Detector and AGC	1 and 5	Cathodes	0
2V7	138	Audio amplifier	2	Cathode	1.3
			7	Second grid	150
			5	Anode	145
2V8	850	Oscillator and quadrupler	2	Cathode	0
			6	Second grid	80
			5	Anode	150
2V9	850	Frequency doubler	2	Cathode	0
			6	Second grid	80
			5	Anode	150

Note . . .

Conditions of measurements:—Input 24V exactly, measured at BATTERY plug. All measurements taken between the points specified and the chassis, using testmeter Type F.

Defects in the rotary transformer

8. Where the symptoms appear to indicate a defective rotary transformer, an examination of the commutators may confirm the diagnosis. If the transformer is in good condition the brush tracks on the commutator should be of a uniform colour

between light chocolate and dark grey, the brush track on the output commutator being normally slightly darker than that on the input commutator. It will be noted that the mica of the output commutator is flush with the segments, and not undercut as in the input commutator.

9. Traces of local burning, or blackened segments occurring at regular or irregular intervals, indicate defects in the rotary transformer. Table 4 lists some of the symptoms which may occur, and suggests probable causes of the same. The majority of the defects listed will necessitate the fitting of a replacement rotary transformer and the return of the defective one for third-line servicing. This

course will be necessary for all defects listed in the table with the possible exception of those indicated by an asterisk. Instructions for the rectification of the latter defects are given in Part 2, Chap. 1 of this publication. If further information regarding the general servicing of rotary transformers is required, reference should be made to A.P.1186D, Vol. 1, Sect. 3.

TABLE 4
Rotary transformer defects

Symptom	Possible cause	Action
Burnt traces on trailing edges of commutator segments Sparkling at commutator (RF interference)	Axis of brushes set to wrong position	Fit replacement machine
	Dirty commutators or brushes	*Clean
	Worn or badly-bedded brushes	*Re-bed, or fit new brushes
	Brushes sticking in holder	*Clean brush and holder
	Insufficient brush pressure	*Usually due to worn brushes
	Overload (mechanical or electrical)	*Check for short-circuit in TR.2002 and for freedom of rotation of armature
	Excessive speed (due to field circuit breakdown)	Fit replacement machine
	Incorrectly set brush axis	Fit replacement machine
	Defective armature	Fit replacement machine
	Bad dynamic balance	Fit replacement machine
Overheating	Defective bearings	Fit replacement machine
	Defective commutator	Fit replacement machine
	Low insulation resistance, or short-circuit in windings	Fit replacement machine
Failure to start	Brush sticking in holder	*Clean brush and holder
Low output voltage	Defective windings	Fit replacement machine
	Dirty commutator	*Clean
Excessive mechanical vibration	High resistance face on brushes	*As for bedding of brushes
	Damaged impeller	*Fit new impeller

* Refer to Part 2, Chap. 1

RESTRICTED


A.P. 2528 M
VOL 4 PART 6
3rd Edition Jan 1966

Superseding 2nd Edition

T.R. 2002
(A.R.I. 18041)

BAY SERVICING SCHEDULES

BY COMMAND OF THE DEFENCE COUNCIL



(Ministry of Defence)

FOR USE IN THE
ROYAL AIR FORCE

RESTRICTED

AMENDMENT RECORD CERTIFICATE

1. This certificate is for Ministry of Defence (Air) A.L.'s only.
2. Amendments are to be inserted in numerical sequence except where Non-Availability slips for particular A.L.s are issued.

A.L. No	A.L. MONTH AND YEAR OF ISSUE	AMENDMENT INCORPORATED SIGNATURE	DATE OF INCORPORATION
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			

LIST OF SECTIONS

- Section 1 - General
- Section 2 - Bay Servicing
- Section 3 - Servicing Diagrams

GENERAL

List of Contents

Chapter	Title	Sheet Nos	No of Sheets
1	Introduction, Safety Precautions and Servicing Notes and Glossary.	1	1
2.	Master Equipment List	1	1

INTRODUCTION, SAFETY PRECAUTIONS
AND SERVICING NOTES AND GLOSSARY

Introduction

1. This schedule has been written to a new pattern which details the minimum amount of servicing necessary to ensure serviceability of the equipment. It is to be used.
 - a. For functional testing after defect rectification.
 - b. To confirm serviceability after incorporation of modifications or STIs.
 - c. To carry out acceptance checks.
2. Servicing is to commence at the 1st. Level, as indicated by 'X' in Column 1, and is to continue at this level unless otherwise directed by the schedule. Similarly, after a change to the 2nd. Level is called for in the schedule, servicing is to continue at this level until reversion to the 1st. Level is indicated.
3. At each point in the 1st. Level procedure where an adjustment is available, the letters 'P' for PASS and 'F' for FAIL indicate the appropriate level at which servicing is to continue.
4. At each complete step in the 2nd. Level checks and tests, the letter 'P' is used to indicate the level at which servicing is to continue if a PASS is obtained. Normally, a failure indicates that a fault is present, but in those rare cases where a further 2nd. Level adjustment may bring the equipment within specification, this is indicated by 'F' in column 2.

Safety Precautions and Servicing Notes

5. The second channel rejection trimmer 2C1 on the chassis side of the receiver unit is not to be adjusted.
6. Alignment of I.F. transformers is not to be attempted.
7. Before T.S.740 is used, 28V supply connector B2/50F/12 is to be terminated as follows:-

Red core to pin 'E' on sealed plug 10H/9560360.

Blue core to pin 'K' on sealed plug 10H/9560360.
8. T.S.740 is to be functionally checked against a known serviceable T.S.740, and is to be used in the horizontal position.

Glossary

9. The servicing operations detailed in this schedule have the meaning given in the Concise Oxford Dictionary except for the following:-
 - a. Check - Make a comparison of a measurement of time, pressure, temperature, resistance, dimension or other quantity with a known figure for that measurement.

9. (Contd)

b. Test - Ascertain, by using the appropriate test equipment, that a component or system functions correctly.

c. Examine - Carry out survey of the condition of an item. For example the condition of an item may be impaired by one or more of the following:-

- (1) Insecurity of attachment.
- (2) Cracks or fractures.
- (3) Corrosion, contamination or deterioration.
- (4) Distortion.
- (5) Loose or missing rivets.
- (6) Chafing, fraying, scoring, or wear.
- (7) Faulty or broken locking devices.
- (8) Loose clips or packing, obstruction of, or leaks from pipelines.
- (9) External damage due to birds, vehicles, stones, wind, etc.
- (10) Discolouration due to overheating, or leaking of fluids, etc.

d. Refit - Fit an item which has previously been removed.

e. Clean - Remove loose dust by Air blast, and clean the whole item including plugs, chassis, wiring, relays, switches etc. using White cotton rag and gasoline, no lead.

WIRELESS

MASTER EQUIPMENT LIST

Sect/Ref	Nomenclature	NATO Code	Qty
	Kits, tool, Air Wireless Fitter to scale A.20, A.P.830, Vol 3, Pt 'A'.		1
10A/14381	Microphone assembly Type 48.		1
10AH/14	Headset Type 9.		1
5QP/17447	Multimeter Type C.T.498.		1
or			
5QP/17001	Multimeter Type 9980.		1
or			
5QP/16411	Multimeter Type 1.		1
10AG/20	Adjuster Type 35.		1
10AG/21	Adjuster Type 36.		1
10D/19216	Junction box Type 170.		1
10HA/13058	Connector Type B23/30A/6.		1
10HA/13059	Connector Type B2/50E/1.		1
10HA/14566	Connector Type D243/51E/3.		1
10HA/14567	Connector Type 10104.		1
10S/16400	Test set Type 193A.		1
10S/16486	Test set Type 740		1
10H/9560360	Plug, sealed, Type M.4. (For use with T.S.740).		1
10S/16379	Testmeter, Type Y.		1
10S/16401	Testmeter, Type 26.		1
	Power adapter comprising:-		
	5E/3767 Cable dunyprensheath 12.		As required
	10H/9560050 Plug, fixed, 2 pole.		1
	10H/9560090 Socket, sealed, M.4.		1
	10H/9560330 Socket, 12-way fixed, medium.		1
	Aerial adapter comprising:-		
	5E/100280 Cable, uniradio 43.		As required
	10H/18589 Plug/socket Type 3.		1
	10H/9560044 Socket, free.		1

MATERIALS

32B/520	Rags, cleaning, best White.	As required
33H/9424829	Grease, XG-250	"
34C/9100454	Gasoline, no lead.	"

POWER SUPPLIES

28V plus 0.5V or minus 1.0V. d.c.

ASSOCIATED PUBLICATIONS

- A.P.2528M Vol 1 A.R.I. 18041 Single channel V.H.F. equipment.
A.P.2536C Vol 1 Common Test Gear for Radio Equipment.

T.R.2002

A.P.2528M Vol 4 Pt 6
3rd Edition, January 1966
Section 2

BAY SERVICING

List of Contents

Chapter	Title	Sheet Nos	No of Sheets
1	Transmitter Receiver	1 - 4	4

LEVEL		Item No	Item	Operation
1	2			
X		1.	Section 1 Chapter 1.	Read.
X		2.	Servicing forms.	Record details of unit,
X		3.	<u>Preparation</u>	
X		3.1	Transmitter - receiver.	
		3.1.1	Cover.	(i) Remove.
		3.1.2	Rear mounting plate.	(ii) Stow.
		3.1.3	Receiver unit.	(i) Separate from transmitter unit as detailed in A.P.2528M Vol 1 Pt 2 Chap 1. (ii) Clean. (iii) Examine. (iv) Connect to test bench. (Fig 3 refers).
		3.1.4	Rotary transformer.	(i) Clean. (ii) Examine.
		3.1.5	Transmitter unit.	(i) Clean. (ii) Examine. (iii) Lubricate front panel plugs. lightly with grease XG-250. (iv) Connect to test bench. (Fig 3 refers).
X		3.2	Test set Type 740.	
		3.2.1	Test set.	Connect to 28V d.c.
		3.2.2	Upper meter zero control.	Adjust for reading at junction of Red/Green sectors.
		3.2.3	On/Off switch.	Set to 'ON' and allow 5 minute warm up period.
		3.2.4	Lower meter.	Check reading is between the limits 27 to 28.5 volts.

LEVEL		Item No	Item	Operation																						
1	2																									
		3.2.5	Service Selector switch.	Set to position listed below and check upper meter needle indicates appropriate reading:-																						
				<table border="1"> <thead> <tr> <th>SWTCH POS'N</th> <th>UPPER METER READING</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>Reject 50 PLUS OR MINUS 4 Divs</td> </tr> <tr> <td>B</td> <td>Central PLUS OR MINUS 2 Divs</td> </tr> <tr> <td>C</td> <td>Central PLUS OR MINUS $\frac{1}{2}$ Divs</td> </tr> <tr> <td>D</td> <td>Reject 50 PLUS OR MINUS 4 Divs</td> </tr> <tr> <td>E</td> <td>Reject 50 PLUS OR MINUS 4 Divs</td> </tr> <tr> <td>F</td> <td>Pass 50 PLUS OR MINUS 4 Divs</td> </tr> <tr> <td>G</td> <td>Central PLUS OR MINUS $\frac{1}{2}$ Divs</td> </tr> <tr> <td>H</td> <td>Central PLUS OR MINUS $\frac{1}{2}$ Divs</td> </tr> <tr> <td>J</td> <td>Reject 50 PLUS OR MINUS 4 Divs</td> </tr> <tr> <td>K</td> <td>Reject 50 PLUS OR MINUS 4 Divs</td> </tr> </tbody> </table>	SWTCH POS'N	UPPER METER READING	A	Reject 50 PLUS OR MINUS 4 Divs	B	Central PLUS OR MINUS 2 Divs	C	Central PLUS OR MINUS $\frac{1}{2}$ Divs	D	Reject 50 PLUS OR MINUS 4 Divs	E	Reject 50 PLUS OR MINUS 4 Divs	F	Pass 50 PLUS OR MINUS 4 Divs	G	Central PLUS OR MINUS $\frac{1}{2}$ Divs	H	Central PLUS OR MINUS $\frac{1}{2}$ Divs	J	Reject 50 PLUS OR MINUS 4 Divs	K	Reject 50 PLUS OR MINUS 4 Divs
SWTCH POS'N	UPPER METER READING																									
A	Reject 50 PLUS OR MINUS 4 Divs																									
B	Central PLUS OR MINUS 2 Divs																									
C	Central PLUS OR MINUS $\frac{1}{2}$ Divs																									
D	Reject 50 PLUS OR MINUS 4 Divs																									
E	Reject 50 PLUS OR MINUS 4 Divs																									
F	Pass 50 PLUS OR MINUS 4 Divs																									
G	Central PLUS OR MINUS $\frac{1}{2}$ Divs																									
H	Central PLUS OR MINUS $\frac{1}{2}$ Divs																									
J	Reject 50 PLUS OR MINUS 4 Divs																									
K	Reject 50 PLUS OR MINUS 4 Divs																									
P	F		<u>Test Set Calibration</u>																							
	X	4																								
	X	4.1	Test set Type 740.																							
		4.1.1	Front and rear securing screws.	Slacken off, and hinge back covers.																						
		4.1.2	Service Selector switch.	(i) Set to 'H' and adjust R.V.8 until needle is in centre of upper meter. (ii) Set to 'A' and adjust R.V.1 for meter reading of Reject 50. (iii) Set to 'J' and adjust R.V.12 for meter reading of Reject 50. (iv) Set to 'F' and check reading is Pass 50 PLUS OR MINUS 1 division repeating Operations (1) to (iii) as necessary.																						
		4.1.3	Rear panel.	Close, and tighten securing screws.																						
		4.1.4	Controls R.V.3 and R.V.4.	Using calibration chart in test set lid, set controls to pass levels of 1 watt and 60 per cent modulation depth respectively.																						
P		4.1.5	Front panel.	Close, and tighten securing screws.																						
D.M.050345 (8A)				Continued																						

LEVEL		Item No	Item	Operation
1	2			
X		5.	<u>Transmitter Tuning and Power Output Checks</u>	
X		5.1	J.B.170.	
		5.1.1	On/Off switch.	Set to 'ON'.
		5.1.2	Recv/Trans switch.	Set to 'RECV'.
X		5.2	Bench power supply.	Switch on and allow a 5 minute warm-up period.
X		5.3	T.S.740 Service Selector switch.	Set to 'A'.
X		5.4	J.B.170 Recv/Trans switch.	Set to 'TRANS' and check T.S.740 lower meter reading is between the limits 27 to 28.5 volts.
X		5.5	Testmeter Type 26.	(i) Connect to test point IPL5/3 on transmitter unit, and check meter reading does not exceed 150 microA. (ii) Transfer to test point IPL4/3 and adjust capacitor 1C10 for maximum meter reading. (iii) Transfer to test point IPL4/2 and adjust capacitor 1C15 for maximum meter reading. (iv) Transfer to test point IPL4/1 and tune 1C20 for maximum meter reading. (v) Disconnect.
X		5.6	Capacitor 1C24. (Transmitter unit).	Adjust for maximum reading in T.S.740 upper meter Green sector.
X		6.	<u>Transmitter Modulation Depth and Noise Level</u>	
X		6.1	T.S.740 Service Selector switch.	Set to 'B' and 'C' in turn checking upper meter reading is in Green sector in each case.
X		7.	<u>Transmitter Sidetone Check</u>	
X		7.1	J.B.170.	Disconnect jack plug and insert headset.


LEVEL		Item No	Item	Operation
1	2			
X		7.2	Headset.	(i) Speak into microphone and ensure sidetone output is clearly audible. (ii) Disconnect, and reconnect jack plug to J.B.170.
X		7.3	J.B.170 Recv/Trans switch.	Set to 'RECV'.
X		8.	<u>Receiver Local Oscillator Tuning</u>	
X		8.1	Testmeter Type Y.	(i) Connect to test point 2PL2/2 on receiver unit, and check meter reading does not exceed 85 microA. (ii) Transfer to test point 2PL2/3 and adjust capacitor 2C49 for maximum meter reading. (iii) Tune 2C53 for minimum meter reading. Note:- Meter reading variation is very small. (iv) Disconnect.
X		9.	<u>Receiver Tuning</u>	
X		9.1	T.S.740.	
		9.1.1	Service Selector switch.	Set to 'E'.
		9.1.2	Frequency control.	Set to 121.5 Mc/s.
		9.1.3	Set R.F. control.	Adjust for scale reading designated Set R.F. in lower meter.
		9.1.4	Press-for-High Level button.	Depress.
		9.1.5	Frequency control.	Adjust for maximum reading in upper meter Green sector.
		9.1.6	Press-for-High Level button.	Release.
X		9.1.7	Frequency control.) Adjust for maximum reading in test set upper meter Green sector.)
		9.2	Capacitors 2C4 and 2C5 (Receiver unit)	
X		9.3	T.S.740 Set R.F. control.	Adjust for scale reading of Set R.F. in lower meter.
X		9.4	R.V.1 on receiver unit.	Adjust for reading of 25 in lower meter Green Sector.

LEVEL		Item No	Item	Operation
1	2			
X		10.	Assistance will be required to carry out this Item. <u>Receiver and Transmitter Quality Checks</u>	
X		10.1	T.S.740.	
		10.1.1.	Sockets JK.1 and JK.2.	Plug in headsets.
		10.1.2	Service Selector switch.	Set to 'G'.
X		10.2	Headsets.	(i) Speak into microphone at JK.1 and adjust T.S.740 Frequency control for maximum audio output at JK.2. (ii) Ensure availability of good quality audio output at JK.2. Note:- Audio output will be lower than normal.
X		10.3	T.S.740 Service Selector switch.	Set to 'H'.
X		10.4	J.B.170 Recv/Trans switch.	Set to 'TRANS'.
X.		10.5	Headsets.	Speak into microphone at JK.2 and ensure availability of good quality audio output at JK.1.
X		10.6	J.B.170 Recv/Trans switch.	Set to 'RECV'.
X		11.	<u>General</u>	
X		11.1	J.B.170 On/Off switch.)	
X		11.2	T.S.740 On/Off switch.)	Set to 'OFF'.
X		11.3	Bench power supply.)	
X		11.4	Headsets.	Disconnect.
X		11.5	T.S.740.	Disconnect from 28V. d.c. supply.
X		11.6	Transmitter - receiver.	Disconnect from test bench installation.

SERVICING DIAGRAMS


List of Contents

Figure	Title
1	Power adapter.
2	Aerial adapter.
3	Test Bench Installation.




POWER ADAPTER

FIG. 1.



AERIAL ADAPTER

FIG. 2.



TEST BENCH INSTALLATION

FIG. 3.








Fig. 9

Transmitter unit Type 98 - circuit

Fig. 9

RESTRICTED




Fig.10

Receiver unit Type 127 - circuit

Fig. 10