ELECTRICAL AND MECHANICAL ENGINEERING REGULATIONS (By Command of the Defence Council)

CONDITIONS OF RELEASE

(Applicable to copies supplied with Ministry of Defence approval to Commonwealth and Foreign Governments)

- 1. This document contains classified UK information.
- 2. This information is disclosed only for official use by the recipient Government and (if so agreed by HM Government) such of its contractors, under seal of secrecy, as may be engaged on a defence project. Disclosure or release to any other Government, national of another country, any unauthorized person, the Press, or in any other way would be a breach of the conditions under which the document is issued.
- 3. This information is to be safeguarded under rules designed to give the same standard of security as those maintained by HM Government in the UK.

REJECTOR UNITS, B47 AND B48

TECHNICAL HANDBOOK - TECHNICAL DESCRIPTION

INTRODUCTION

Role and purpose

1. These rejector units are used in vehicle installations to limit interference in the B47 receiver from the C42 transmitter, or in the B48 receiver from the C45 transmitter. The interference is caused by the local transmitter, which induces an unwanted signal into the local receiver antenna, thus limiting the number of usable channels or the facilities offered.

Performance

2. Provided the frequency separation between the wanted and unwanted signals is not less than 2Mc/s, then each unit when correctly tuned attenuates the unwanted signal by 30dB or more, but passes the wanted signal with minimum loss (not greater than 4dB).

Brief description

3. Both units contain fixed and variable reactances, forming two tuned circuits which select and reject the wanted and unwanted frequencies respectively. A level meter is utilized as a tuning indicator for both tuned circuits. The two rejector units are identical in appearance and differ internally only in respect of the values of their input and output inductors. These govern the frequency coverage of 36-60Mc/s for the B47 and 23-38Mc/s for the B48.

Construction

4. Each unit is housed in a sealed die-cast metal box 7.1/8 in. wide, 5 in. high, 6 in. deep. Λ desiccator is fitted in the rear of the case while tuning controls and the level indicator are mounted in the front panel, together with an earth terminal and the Burndept type coaxial input and output plugs. Λ friction lock secures the tuning controls once they have been correctly set.

Issue 1, 6 Nov 64

TELECOMMUNICATIONS L 102

ELECTRICAL AND MECHANICAL ENGINEERING REGULATIONS

DETAILED TECHNICAL DESCRIPTION

Fig 2001

Overall principle

Basically the unit consists of two tuned circuits, a series and a parallel circuit. The series circuit L3 and C4, is tuned to the unwanted frequency and provides a low impedance path to earth. At the wanted frequency this series circuit will appear inductive or capacative. The parallel circuit consists of Cl, Ll and 14 plus the reactance of the series circuit, and is tuned to the wanted frequency. The complete unit is thus a shunt across the receiver input which presents a high impedance to the wanted signal and a very low impedance to the unwanted signal. Coils Ll and L4 are tapped in order to obtain the necessary impedance matching.

Operation

Initially Cl is tuned approximately to the frequency of the wanted signal. C4 is then tuned for maximum rejection of the unwanted signal, indicated by minimum reading on the level meter. Cl is now accurately tuned to obtain a maximum meter reading at the wanted frequency. Adjustment of C4 is little affected by the rest of the circuit whereas the adjustment of Cl depends considerably on the setting of C4. The frequency separation between wanted and unwanted signals is normally not less than 2Mc/s otherwise the series circuit will attenuate the wanted signal excessively.

Level meter

The level meter provides means for tuning the resonant circuits by measuring the voltage developed across them. The signal is rectified by MRI and fed to the moving coil meter via Rl and R2. C3 is an r.f. by-pass across the meter, while L2 provides a d.c. return path. The rectifier MR2 is a non-linear shunt whose impedance decreases as the applied voltage increases. It thus increases the useful range of the meter and protects it against overloads whilst retaining the high sensitivity to low level signals.

Note: The next page is Page 1001

Cct ref	Description	Value Tol	Rating	Part No
And the second of the second o	RESISTORS	S AND CAPACITOR	S	м <u>до (Model manifements) и стоя поставательностью стоя продуства в печаненного услова двар^{днаг}о</u>
R1 R2 C1 C2 C3 C4	fixed, comp fixed, film variable, air dielectric fixed, ceramic dielectric fixed, paper dielectric variable, air dielectric	5.6k 5 1.2k 5 378p max 2.2p ±.5p 0.01µ 20 73.6p max	0.25W 0.25W 750W d.c. 250V d.c.	Z/5905-99-021-5331 Z/5905-99-021-5251 Z1/ZA 55148 Z/5910-99-011-8337 Z/5910-99-012-0113 Z1/ZA 55147
Cct ref	Description	Deta	ils	Part No
generated here and here and here an electrical and an electrical and an electrical and electrica	II	NDUCTORS		
L1 (B47) L1 (B48) L2 (B47 & B48) L3 (B47 & B48) L4 (B47) L4 (B48)	R.F., fixed screened R.F., fixed screened R.F., unscreened R.F. fixed unscreened R.F., fixed screened R.F., fixed screened	3 turns 3.1/2 turns 10µH 11 turns 3 turns 3.1/2 turns		Z1/ZA 55193 Z1/ZA 56226 Z1/ZA 55180 Z1/ZA 55190 Z1/ZA 55193 Z1/ZA 56226
	MIS	CELLANEOUS		
MR1 MR2 PL1 PL2 M1	Semi-conductor device, diode Semi-conductor device, diode Plug, electrical, R.F., fixed, female shell Plug, electrical, R.F., fixed, female shell Meter, non-sealed	CV425 CV425 0.5mA f.s.d		z/5960-99-000-0425 z/5960-99-000-0425 z/5935-99-011-9484 z1/6625-99-949-092

Table 2001 - Components list





Fig 2001 - Circuit diagram



T 1-2002 2003/2

Fig 2002 - Component board




Fig 2003 - Overall view top




Fig 2004 - Overall view underside

EME/8c/(A)2603

END

RESTRICTED

ELECTRICAL AND MECHANICAL ENGINEERING REGULATIONS

(By Command of the Defence Council)

TELECOMMUNICATIONS
L 102

REJECTOR UNITS, B47 AND B48

FORWARD CODING

Note: The following list of Assembly Codes must be used in conjunction with EMER Mgmt J 021 Part 4

Assembly code	Designation		
0001	Rejector unit, B47		
0002	Rejector unit, B48		

6-502 (Data Centre)

END

Issue 1, 28 Mar 67

Distribution - Class 334. Code No 3

Page 2001